

WAN



Tsunami MP.11

Version 1.1

Installation and Management Guide

Notices

COPYRIGHT

©2003 Proxim Corporation, Sunnyvale, CA. All rights reserved. Covered by one or more of the following U.S. patents: 5,231,634; 5,875,179; 6,006,090; 5,809,060; 6,075,812; 5,077,753. This manual and the software described herein are copyrighted with all rights reserved. No part of this publications may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form by any means without the written permission of Proxim Corporation.

TRADEMARKS

Tsunami, Proxim, and the Proxim logo are trademarks of Proxim Corporation. All other trademarks mentioned herein are the property of their respective owners.

Contents

Copyright.....	2
Trademarks.....	2
CHAPTER 1. OVERVIEW.....	4
Wireless Network Topologies	5
Active Ethernet.....	6
CHAPTER 2. INSTALLATION.....	7
Identifying Network Topology and Equipment	7
Finding a Suitable Location	7
Installation.....	8
Switching On the MP.11	14
Installing Documentation and Software	15
Mounting the MP.11.....	16
CHAPTER 3. MANAGEMENT OVERVIEW	18
MP.11 IP Address	18
Web Interface Overview	21
Command Line Interface Overview	22
CHAPTER 4. BASIC MANAGEMENT	25
Rebooting and Resetting	26
General Settings	28
System Configuration.....	29
IP Configuration	30
Monitoring Settings	36
Security Settings	38
Upgrading the MP.11	40
CHAPTER 5. WEB INTERFACE	41
Status	41
Configure	42
Monitor	56
Commands.....	63
CHAPTER 6. COMMAND LINE INTERFACE.....	66
Introduction	66
Using Command Help.....	66
Viewing and Changing Parameters	67
Entering Strings	67
Working with Tables.....	68
CHAPTER 7. PROCEDURES.....	70
TFTP Server Setup	70
Image File Download	71
Configuration Backup.....	72
Configuration Restore	73
Soft Reset to Factory Default.....	74
Hard Reset to Factory Default	74
Forced Reload	75
Image File Download with the Bootloader	75
CHAPTER 8. SPECIFICATIONS.....	78
Hardware Specifications	78
Radio Specifications	79
CHAPTER 9. TROUBLESHOOTING	80
LED Indicators	80
MP.11 Connectivity Issues	81
Setup and Configuration	84
GLOSSARY	87

Chapter 1. Overview

The Tsunami MP.11 is a flexible wireless outdoor router that lets you design solutions for point-to-point links and point-to-multipoint networks.

The MP.11 is a product family, comprising several products (such as the mp.11 2411 Base Station and the MP.11 2411 Residential Subscriber unit). For simplification, all products that are part of the MP.11 Product Family are referred to as MP.11.

Some of the key features of the MP.11 are:

- The use of a highly optimized protocol for outdoor situations
- Routing and bridging capability
- Asymmetric bandwidth management
- Management through a Web Interface, a Command Line Interface (CLI), or Simple Network Management Protocol (SNMP)

Before installing and using the MP.11, Proxim recommends you review the following chapters of this manual first:

Chapter 1 “Overview” (this chapter)

This chapter gives an overview of the content of this manual as well as wireless network topologies and combinations that can be built with the MP.11.

Chapter 2 “Installation” on page 7

This chapter gives detailed installation instructions for the MP.11.

Chapter 3 “Management Overview” on page 18

This chapter explains how to access the MP.11 to manage it for configuration or maintenance.

Chapter 4 “Basic Management” on page 25

This chapter explains the most common settings used to manage the MP.11.

Chapter 5 “Web Interface” on page 41

This chapter depicts the Web Interface in a hierarchical manner, so you can easily find details about each item.

Chapter 6 “Command Line Interface” on page 66

The Command Line Interface (CLI) is an alternative to the Web Interface. This chapter tells you how to obtain help about commands and how to handle strings, tables, and so on.

The remaining chapters contain supplementary information you may not need immediately.

If you are already familiar with this type of product, you can use the “Quick Install Guide” to install the MP.11.

WIRELESS NETWORK TOPOLOGIES


You can use the MP.11 to set up the following types of topologies:

- Point-to-Point Link ([below](#))
- Point-to-Multipoint Network ([on page 6](#))

A link between two locations always consists of a Base and a Satellite station. A station is a radio set up as either a Base Station or a (Residential) Subscriber Unit. A Base station can, depending upon its configuration, connect to one or more Satellite stations. A Satellite station, however, can only connect to one Base station.

Point-to-Point Link

With a Base and a Satellite station or QuickBridge 11 kit, it is easy to set up a wireless Point-to-Point link as depicted in the following figure.




The Point-to-Point link function lets you set up a connection between two locations as an alternative to:

- Leased lines in building-to-building connections
- Wired Ethernet backbones between wireless access points in “hard-to-wire” environments

Point-to-Multipoint Network

If you want to connect more than two buildings, you can set up a single Point-to-Multipoint network with a single Base interface and multiple Satellite interfaces, as depicted in the following figure.



In this figure, the system is designed as follows:

- The central building **b** is equipped with a Base interface, connected to either an omni-directional, or a wide angle antenna.
- The two other buildings **a** and **c** are both equipped with a Satellite interface connected to a directional antenna.

ACTIVE ETHERNET

The MP.11 is equipped with an 802.3af-compliant Active Ethernet module. Active Ethernet delivers both data and power to the radio over a single Ethernet cable. If you choose to use Active Ethernet, there is no difference in operation; the only difference is the power source.

- The Active Ethernet integrated module receives –48 VDC over a standard Cat 5 Ethernet cable.
- To use Active Ethernet, you must have an Active Ethernet hub (also known as a power injector) connected to the network. The Active Ethernet hub is not a repeater and does not amplify the Ethernet data signal.
- The cable length between the Active Ethernet hub and the radio should not exceed 100 meters (approximately 325 feet).
- If connected to an Active Ethernet hub and an AC power supply simultaneously, the radio draws power from Active Ethernet.
- Maximum power supplied to an MP.11 is 11 Watts; the unit typically draws less than 7.5 Watts.

Chapter 2. Installation

This chapter describes the steps required to install the MP.11 installation steps, such as:

- Identifying Network Topology and Equipment [below](#)
- Finding a Suitable Location [below](#)
- Installing the MP.11 [on page 10](#)
- Switching On the MP.11 [on page 14](#)
- Installing Documentation and Software [on page 15](#)
- Mounting the MP.11 [on page 16](#)

Note: The installation does not cover the mounting and connection of antennas. See the *Tsunami MP.11 Antenna Installation Guide*.

If you are already familiar with this type of product, you can use the *Quick Install Guide* for streamlined installation procedures.

IDENTIFYING NETWORK TOPOLOGY AND EQUIPMENT

The MP.11 can be used in various network topologies and combinations. You find more details in “Wireless Network Topologies” in Chapter 1 [on page 5](#). Make sure all equipment is available before installing the MP.11. The required equipment depends upon the wireless network topology that you want to build.

The MP.11 is designed for indoor placement. You can connect the MP.11 to an outdoor antenna installation with an optional antenna kit. See the *Tsunami MP.11 Antenna Installation Guide* for details.

WARNING! *If you want to connect the MP.11 to an outdoor antenna system, consult the appropriate manufacturers’ documentation for additional regulatory information, safety instructions, and installation requirements.*

FINDING A SUITABLE LOCATION

To make optimal use of the MP.11, you must find a suitable location for the hardware. The radio range of the MP.11 largely depends upon the position of the antenna. Proxim recommends you do a site survey, observing the following requirements, before mounting the MP.11 hardware.

- The location must allow easy disconnection of the unit from the power outlet if necessary.
- The unit must not be covered and the air must be able to flow freely around the unit.
- The unit must be kept away from vibration, excessive heat, and humidity, and kept free from dust.
- The installation must conform to local regulations at all times.

- If you do not use Active Ethernet, the unit must be connected to proper grounding using the Faston plug on the metal case (regular 6.3 mm width plug).



Note: Whether Power-over-Ethernet or local power is used, the metal case must ALWAYS be grounded (through the Faston connector or the ground wire screwed to the metal case in another manner).

INSTALLATION

The MP.11 supports two power methods—an AC power outlet and Active Ethernet. The power supply accepts an input AC voltage in the range of 100-240 VAC.

The installation procedure [on page 10](#) provides instructions for attaching both the power and Ethernet connectors.

WARNING! For your own safety, use only the power cord supplied with the unit. The metal case of the MP-11 must be grounded through the ground connection that is provided on the metal case. The antenna grounding, the surge arrestor, and the MP.11 housing must be bonded together and grounded in one location to avoid ground current loops.

In situations without an external antenna (for example, during a desk tryout), the antenna cable is not required.

The Product Package

Each MP.11 comes with the following:

- One metal base for ceiling or desktop mounting (includes two screws)
- Mounting hardware
 - Four 3.5 mm x 40 mm screws
 - Four 6 mm x 35 mm plugs
- One power supply
- One Tsunami MP.11 Installation CD-ROM containing:
 - Software Installation Package (starts automatically when CD is inserted in CD-ROM drive; can be started by double-clicking SETUP.EXE).
 - Online Help
 - Documentation (Quick Install Guide, Installation and Configuration Guide)
 - ScanTool (a utility with which you can obtain or set the IP address of the MP.11 for access; see “ScanTool” [on page 18](#) for more information).
 - TFTP Server (which lets you transfer files across the network). You can download configuration files as well as image files for embedded software upgrades, and you can upload files from the MP.11 for backup. Here *downloading* means transferring files to the MP.11 and *uploading* means transferring files in the opposite direction.


Note: All software CD-ROMs that come with your Tsunami products include a **readme.txt** or **readme.html** file. This file contains information about the software version and drivers. You are advised to print and read the **readme** file prior to installing your Tsunami products, as it may contain additional information that was not available when this document was printed.

Installing the MP.11

To install the MP.11:

1. Unpack the unit and accessories from the shipping box.

The MP.11 kit contains the following items:




Shown in picture:

- 1 Tsunami MP.11 unit
- 2 Mounting Stand
- 3 Documentation and Software CD-ROM
- 4 Wall mounting hardware
- 5 Power supply with power cord

The shipment also includes the *Tsunami MP.11 Quick Install Guide*, the *Tsunami MP.11 Release Notes*, and regulatory information.

2. If you intend to install the unit free-standing, or if you intend to mount it to the ceiling, use a Phillips screwdriver to attach the metal base to the underside of the unit. The metal base and screws are provided (see "Mounting the MP.11" on page 16 for more information).




3. Unlock the unit's cable cover. To release the cable cover, press down on the cable cover lock located in the front center of the unit.



4. Remove the cable cover.




5. Remove the front cover from the unit (the side with the LED indicators, shown in the figure on left); then remove the back cover (figure on right).



6. Connect the grounding wire to the MP.11 using the Faston plug on the metal case, next to the power plug.



7. Connect one end of an Ethernet cable to the Ethernet port. The other end of the cable should not be connected to another device until after installation is complete.
 - Use a straight-through Ethernet cable if you intend to connect the MP.11 to a hub, switch, patch panel, or Active Ethernet power injector.
 - Use a cross-over Ethernet cable if you intend to connect the MP.11 to a single computer.
8. If you are not using Active Ethernet, or you want to connect the MP.11 to Active Ethernet and AC power simultaneously, attach the AC power cable to the MP.11's power port.



9. Once attached, the power cable locks into place. To disconnect the power cable, slide back the black plastic fitting and gently pull the cable from the connector.
10. Connect the free end of the Ethernet cable to a hub, switch, patch panel, Active Ethernet power injector, or an Ethernet port on a computer.
11. If using AC power, connect the power cord to a power source (such as a wall outlet) to turn on the unit.
12. Place the unit in the final installation location (see "Mounting the MP.11" on page 16 for details).


13. Replace the back cover, front cover, and cable cover. Be careful to avoid trapping the power and Ethernet cables when replacing the cable cover.

Attaching a Kensington Security Lock (Optional)

If so desired, you can attach a Kensington lock to secure the cable cover into place. This protects the unit from unauthorized tampering.

The MP.11 enclosure includes a Kensington Security Slot for use with a Kensington locking mechanism. When properly installed, a Kensington lock can prevent unauthorized personnel from stealing the MP.11. In addition, the Kensington lock secures the cable cover in place, which prevents tampering with the Ethernet and power cables.

The Kensington Security Slot is shown in the following figures (the figure on the left shows the slot with the cable cover attached; the figure on the right shows the slot with the cable cover removed).




For information about Kensington security solutions, go to <http://www.kensington.com> .

SWITCHING ON THE MP.11

The MP.11 can be powered by a power supply or by Active Ethernet through an Active Ethernet splitter. Depending upon the powering method, you can switch the MP.11 on by:

- Plugging the power cord of the power supply into an AC power outlet
- Connecting the Active Ethernet splitter to the Ethernet cabling

When the power is switched on, the MP.11 performs start-up diagnostics. When the start-up is completed, the LEDs show the operational state of the MP.11. The following table shows the status of the three LEDs when the MP.11 is operational; the fourth LED is unused.



Power	Ethernet Link	Wireless Link
OFF when no power is present or malfunctioning Green when power is present and the unit is operational. Amber when the unit cannot get a dynamic IP address, or in Forced Reload state when Ethernet LED also is amber.* Red when there is a fatal error in the unit.	OFF when not connected. Green when connected at 10 Mbps. Blinking Green when data sent. Amber when connected at 100 Mbps, or in Forced Reload state when Power LED also is amber.* Blinking Amber when data sent. Red when there is an error in data transfer.	OFF wireless interface is up properly, but no wireless link established. Green immediately after connecting a link. Blinking Green when data sent. Red when the wireless interface is down.
*See "Forced Reload" on page 75.		

INSTALLING DOCUMENTATION AND SOFTWARE

The MP.11 also comes with documentation and software on a CD-ROM.

To install the documentation and software on a computer or network:

1. Place the CD-ROM in a CD-ROM drive. The installer normally starts automatically. You can also start the installer manually by running the **setup.exe** program in the root directory of the CD-ROM.
2. Click the **Install Help and Software** button and perform the necessary steps.

The CD-ROM contains the following documentation and software:

Online help

This is the help for the Web Interface. It is stored on your computer or network so it is always available. The help is launched by clicking the question mark button in the Web Interface.

Documentation

Documentation also is available in an electronic (PDF) form, including the *Tsunami MP.11 Installation and Management Guide*, *Tsunami MP.11 Antenna Installation Guide*, and *Tsunami MP.11 Quick Install Guide*.

ScanTool

The ScanTool program is a utility with which you can obtain or set the IP address of the MP.11 for management access. See “ScanTool” [on page 18](#) for details.

TFTP server

The TFTP (Trivial File Transfer Protocol) server lets you transfer files across the network. You can download configuration and license files, as well as image files for embedded software upgrades, and you can upload files from the MP.11 for backup. Here downloading means transferring files to the MP.11 and uploading means transferring files in the opposite direction.

MOUNTING THE MP.11

The following are the mounting options for the MP.11:

- Desktop Mount
- Wall Mount
- Ceiling Mount


Desktop Mounting

This procedure consists of attaching the metal base to the MP.11 unit. See “Installing the MP.11” on [page 10](#).

Wall Mounting

Follow these steps to mount the MP.11 on a wall.

1. Identify the location where you intend to mount the unit.
2. Unplug the MP.11’s power supply, if necessary.
3. Use a Phillips screwdriver to remove the metal base from the underside of the MP.11, if necessary.
4. Press down on the cable cover lock to release the cable cover (see “Installing the MP.11” on [page 10](#) for illustrations).
5. Remove the cable cover from the unit (see “Installing the MP.11” on [page 10](#) for illustrations).
6. Remove the front cover from the unit (see “Installing the MP.11” on [page 10](#) for illustrations).
7. Remove the back cover from the unit (see “Installing the MP.11” on [page 10](#) for illustrations).
8. Place the back cover on the mounting location and mark the center of the three mounting holes.



9. Remove the cover from the wall and drill a hole at each of the locations you marked above. Each hole should be wide enough to hold a mounting plug (which is 6 mm x 35 mm).
10. Insert a plug into each hole. The MP.11 comes with four 6 mm x 35 mm plugs; you only need to use three of these when wall-mounting the unit.

11. Insert a screw into each of the mounting holes molded into the back cover. The MP.11 comes with four 3.5 mm x 40 mm pan-head screws; you only need to use three of these when wall-mounting the unit.
12. Insert the screws into the wall plugs. Use a screwdriver to tighten the screws and attach the back cover to the wall. In the following example, the back cover is mounted upside down (the two holes are at the bottom).
13. Attach Ethernet and power cables to the MP.11 unit, if necessary.
14. Snap the unit into the back cover, replace the front cover, and replace the cable cover.
15. Turn on the MP.11 (see “Switching On the MP.11” [on page 14](#)).

Ceiling Mounting

Follow these steps to mount the MP.11 to a ceiling.

1. Unplug the MP.11's power supply, if necessary.
2. Use a Phillips screwdriver to attach the metal base to the underside of the MP.11, if necessary. See “Installing the MP.11” [on page 10](#) for an illustration.
3. Feed a mounting screw through each of the four rubber feet. The MP.11 comes with four 3.5 mm x 40 mm pan-head screws.



4. Remove the screws from the rubber feet.
5. Turn the MP.11 upside down and position the base against the ceiling where you want to mount the unit.
6. Mark the center of the four mounting holes in the rubber feet.
7. Set the MP.11 aside and drill a hole at each of the locations you marked above. Each hole should be wide enough to hold a mounting plug (6 mm x 35 mm).
8. Insert a plug into each hole. The MP.11 comes with four 6 mm x 35 mm plugs.
9. Insert the screws into the holes you made previously in the rubber feet.
10. Insert the screws into the wall plugs. Use a screwdriver to tighten the screws and attach the MP.11's metal base in the ceiling.

Chapter 3. Management Overview

This chapter describes how to gain access to the MP.11 for configuration and management. Three interfaces are provided for viewing or changing the MP.11's settings:

Web Interface on page 21

The Web Interface is a graphical interface based upon Web pages from a built-in Web server.

Command Line Interface on page 22

The Command Line Interface (CLI) is a text-based interface using typed commands.

SNMP

You also can use the Simple Network Management Protocol (SNMP) to configure and manage the MP.11. See "SNMP" on page 47 for setup procedures.

Connecting to the MP.11 requires a direct physical connection with an Ethernet cross-over cable, a serial RS-232C cable, or a connection through the network.

For the serial connection, you can use only the CLI to configure and manage the MP.11. The other connections allow the use of the Web Interface, SNMP, and the CLI. These other connections require the IP address of the MP.11 before you can use the Web Interface, SNMP, or the CLI. See "MP.11 IP Address" below for more information.

You can also manage the MP.11 without an IP address by accessing the MP.11 through the serial port with a terminal program such as HyperTerminal.

Note: The MP.11 includes integrated management that makes the OR Manager obsolete. The OR Manager is suitable only for the OR-500, OR-1000, and OR-1100.

MP.11 IP ADDRESS

Because each network is different, an IP address suitable for your network must be assigned to the MP.11. You will need the IP address of the MP.11 to use its Web Interface, SNMP, or the CLI for configuration and management.

The MP.11 either obtains its IP address automatically through DHCP or it must be set manually. With ScanTool, you can find out the current IP address of the MP.11 and, if necessary, change it so that is appropriate for your network.

ScanTool

The IP address of the MP.11 on the connected local network can be set and retrieved using ScanTool. Other basic parameters can be managed as well. ScanTool is included on the documentation and software CD-ROM.

Static or Dynamic IP Address

The MP.11 can use either a static or dynamic IP address.

- *Static IP address:* The MP.11 uses the IP address you have set manually.
- *Dynamic IP address:* The MP.11 receives its IP address from a DHCP server when it is switched on or rebooted.


Static IP Address

The MP.11 is shipped with the static IP address 10.0.0.1 configured.


If you want to set the IP address manually:

1. Run ScanTool on a computer connected to the same LAN subnet as the MP.11, or directly connected to the MP.11 with a cross-over Ethernet cable.

ScanTool scans the subnet for MP.11 units and displays the found units in the main window. The following figure shows an example of the main window. If necessary, click **Rescan** to re-scan the subnet and update the display.



2. Select the MP.11 for which you want to set the IP address and click **Change**. The **Change** dialog window is displayed, as shown in the following window.



The image shows a 'Change' dialog box with a blue title bar and a close button. It contains several input fields and radio buttons for configuring an MP.11 device. The fields are: MAC Address (00-02-2d-48-14-57), Name (Device Name), IP Address Type (Static selected, Dynamic unselected), IP Address (10.0.0.1), Subnet Mask (255.255.255.0), Gateway IP Address (10.0.0.1), TFTP Server IP Address (10.0.0.2), Image File Name (FILENAME), and Read/Write Password (empty). At the bottom are OK and Cancel buttons.

MAC Address	00-02-2d-48-14-57
Name	Device Name
IP Address Type	<input type="radio"/> Static <input checked="" type="radio"/> Dynamic
IP Address	10.0.0.1
Subnet Mask	255.255.255.0
Gateway IP Address	10.0.0.1
TFTP Server IP Address	10.0.0.2
Image File Name	FILENAME
Read/Write Password	

3. Ensure that **Static** is selected as the **IP Address Type** and fill in the **IP Address** and **Subnet Mask** suitable for the LAN subnet to which the MP.11 is connected.
4. Enter the **Read/Write Password** (the default value is **public**) and click **OK** to confirm your changes.

The respective MP.11 reboots to make the changes effective.

Dynamic IP Address with DHCP

To obtain the IP address:

1. Run ScanTool on a computer connected to the same LAN subnet as the MP.11, or directly connected to the MP.11 with a cross-over Ethernet cable.
2. Locate the MP.11 for which you want to obtain the IP address. You can find the current IP address in the **IP Address** column.

The MP.11 initially is set with a static IP address of 10.0.0.1.

WEB INTERFACE OVERVIEW

The Web Interface provides a graphical user interface with which you can easily configure and manage the MP.11. This section describes only how to access the Web Interface; the Web Interface itself described in “Chapter 4. Basic Management” on page 25 and “Chapter 5. Web Interface” on page 41.

To use the Web Interface, you need only the IP address of the MP.11. See “MP.11 IP Address” on page 18 for details.

Note: If the connection is slow or you are not able to connect, ensure that you are not using a proxy server for the connection with your Web browser (using the Internet Explorer Tools option).

To access the MP.11 with a Web browser, start your Web browser and enter the IP address of the MP.11. The Web address should appear as **http://<ip address>** (for example, <http://10.0.0.1>). A window such as the following is displayed.



Do not fill in the **User Name**, enter only the password and click **OK**. The default password is **public**.

The **System Status** window of the Web Interface is displayed. You now have access to the Web Interface of the MP.11 with which you can configure and manage it.

COMMAND LINE INTERFACE OVERVIEW

The Command Line Interface (CLI) is a text-based interface with which you can configure and manage the MP.11 by entering commands. This section describes only how to access the CLI; the interface itself is described in “Chapter 6. Command Line Interface” on page 66.

The CLI can be used as an alternative to the Web Interface. You can, for example, quickly change the settings of the MP.11 by running commands in a batch.

The CLI is accessible through the:


- Ethernet port connected through the network or with a cross-over Ethernet cable between the computer and the MP.11
- Serial port of the MP.11

Ethernet Port

To use the CLI through the Ethernet port, you must have a telnet program and the IP address of the MP.11. On most computers, the telnet program is called **telnet**. See “MP.11 IP Address” on page 18 for details.

To access the MP.11 through Ethernet:

1. From the Windows **Start** menu, select **Run**; enter **cmd** and click **OK**.
2. Enter **telnet** followed by the IP address, as shown in the following sample **DOS** command window.



```
C:\WINNT\System32\cmd.exe
Microsoft Windows 2000 [Version 5.00.2195]
(C) Copyright 1985-2000 Microsoft Corp.
C:\>telnet 10.0.0.1
```

3. You are prompted for your password:
Please enter password:
4. Enter the password (the default password is **public**).

You can now use the CLI.

Serial Port

You can also use the CLI through the serial port of the MP.11 with a terminal program such as HyperTerminal. You can use this method for cases in which other access methods cannot be used, or when the IP address of the MP.11 cannot be set or retrieved. Also see “Hard Reset to Factory Default” on page 74.

To use the CLI through the serial port of the MP.11 the following items are required:

- A serial RS-232C cable with a male and a female DB-9 connector. The serial cable must have a minimum of the following connections:

Male Connector		Female Connector
Pin 2	-----→	Pin 2
Pin 3	-----→	Pin 3
Pin 5	-----→	Pin 5

- An ASCII terminal program, such as HyperTerminal.

Proxim recommends you switch off the MP.11 and the computer before connecting or disconnecting the serial RS-232C cable.

To access the MP.11 through the serial port:

1. Start your terminal program.
2. Set the following connection properties; then connect:

COM port	(For example, COM1 or COM2, to which the MP.11 serial port is connected.)
Bits per second	9600
Data bits	8
Stop bits	1
Flow control	none
Parity	none
Line ends	carriage return with line feed

3. Press the RESET button on the MP.11 unit. The terminal program displays Power On Self Test (POST) messages. After approximately 90 seconds it displays:

Please enter password:


4. Enter the password. The default password is **public**.

You can now use the CLI.


HyperTerminal Connection Properties

The serial connection properties can be found in HyperTerminal as follows:

1. Start HyperTerminal and select **Properties** from the **File** menu.
2. In the **Connect using:** drop-down list, select **Direct to Com1** (depending upon the COM port you use) and click **Configure...**; a window such as the following is displayed.



3. Make the necessary changes and click **OK**.
4. From the Hyperterminal **Properties** window, click the **Settings** tab; then click **ASCII Setup...**; a window such as the following is displayed.



5. Ensure that **Send line ends with line feeds** is selected and click **OK**.
6. Click **OK** again to exit the **Properties** window.

HyperTerminal is now correctly configured.

Chapter 4. Basic Management

This chapter describes the initial setup of the MP.11, which lets you set up and monitor the basic features of the MP.11. In most cases, setting up these basic features is sufficient.


A full overview of the Web Interface is provided in “Chapter 5. Web Interface” on page 41; “Glossary” on page 87 provides a brief explanation of the terms used.

The following topics are discussed in this chapter:

- Rebooting and Resetting on page 26
- General Settings on page 28
- Monitoring Settings on page 36
- Security Settings on page 38
- Upgrading the MP.11 on page 40

To use the Web Interface for configuration and management, you must access the MP.11. With ScanTool you can determine the unit's current IP address. Then enter http://<ip address> in your Web browser. See “Chapter 3. Management Overview” on page 18 for details.

The Web Interface consists of Web page buttons and tabs. A tab can also contain sub-tabs. The following figure shows the convention used to guide you to the correct tab or sub-tab.



The Web Interface also provides online help, which is stored on your computer (see “Installing Documentation and Software” on page 15 for details). Launch help by clicking the question mark button in the Web Interface.

REBOOTING AND RESETTNG

Some configuration changes require a restart. There are several ways to restart the MP.11, which are described in the following sub-sections.

Applying Changes

Some changes you make become effective only when the MP.11 is rebooted. A reboot stores configuration information in non-volatile memory and then restarts the MP.11 with the new values (see “Soft Reset to Factory Default” on page 27).

In some cases, the MP.11 reminds you that a reboot is required for a change to take effect. You need not reboot immediately; you can reboot after you have made all your changes.

Note: Saving of the MP.11 configuration occurs only during a controlled reboot. If setting changes are made without a controlled reboot (command), a power outage would wipe out all changes since the last reboot. For example, entering static routes takes effect immediately; however, the routes are not saved until the unit has gone through a controlled reboot. Proxim strongly recommends rebooting immediately when you finish making changes to save your settings.

Rebooting

When you reboot, the changes you have made become effective and the MP.11 is restarted. The changes are saved automatically in non-volatile memory before the actual reboot takes place.

To reboot:


1. Click the **Commands** button, then the **Reboot** tab.
2. Click the **Reboot** button. The MP.11 restarts the embedded software. During reboot, you are redirected to a page showing a countdown timer, and you are redirected to the **Status** page after the timer counts down to 0 (zero). The CLI is disconnected during reboot. This means that a new telnet session must be started.

Related CLI command: `reboot [<number of seconds>]`

Resetting Hardware

If the MP.11 does not respond for some reason and you are not able to reboot, you can restart by means of a hardware reset. This restarts the MP.11 hardware and embedded software. The last saved configuration is used. Any changes that you have made since then are lost.

To reset the hardware, press and release the **RESET** button on the MP.11 unit with, for example, a pencil.



Soft Reset to Factory Default

If necessary, you can reset the MP.11 to the factory default settings. This must be done only when you are experiencing problems. Resetting to the default settings requires you to again configure the MP.11.

To reset to factory default settings:

1. Click the **Commands** button, then the **Reset** tab.
2. Click the **Reset to Factory Default** button. The device configuration parameter values are reset to their factory default values.

If you do not have access to the MP.11, you can use the procedure described in “Hard Reset to Factory Default” on page 74 as an alternative.

Related CLI command: `set sysresettodefaults 1`

GENERAL SETTINGS

This section describes the MP.11 general settings, including displaying the System Status and the configuration of system and IP parameters.

System Status

To view the current system status, click the **Status** button. The **Status** window is the first page you see when you log in.

The screenshot shows the 'Status' window of the Tsunami MP.11 interface. On the left is a sidebar with four buttons: 'Status' (highlighted), 'Configure', 'Monitor', and 'Commands'. The main content area is titled 'Status' and contains two sections: 'System Status' and 'System Traps'.

System Status

IP Address	10.0.0.1	Contact	Contact Name
Name	Wireless Outdoor Router	Location	Contact Location
Object ID	1.3.6.1.4.1.11698.2.4.9	Up Time (DD:HH:MM:SS)	00:00:11:22

System Traps

At the top of the traps section are two buttons: 'Select All' and 'Deselect All'.

	Description	Severity	Time Stamp
<input type="checkbox"/>	OR Cold Started.	Informational	0 days 0 hrs 0 m 0 s

Below the table is a 'Delete' button.

Related CLI command: **show system**

SYSTEM CONFIGURATION

The system configuration page lets you change the MP.11's system name, location name, and so on (see the following System Configuration window). These details help you to distinguish this MP.11 from other routers, and lets you know whom to contact in case of problems. To go to this page, click the **Configure** button and the **System** tab.

Information	
Name	Wireless Outdoor Router
Location	Contact Location
Contact Name	Contact Name
Contact Email	name@Organization.com
Contact Phone	Contact Phone Number
Object ID	1.3.6.1.4.1.11898.2.4.9
Ethernet MAC Address	00:01:2D:01:24:03
Descriptor	Wireless Outdoor Router vBeta Bld#12 v0.98.98 SN- 01241 v0.0
Up Time (DD:HH:MM:SS)	00:00:13:02
Mode of Operation	Bridge

You can enter the following details:

System Name

This is the system name for easy identification of the MP.11.

Location

This field can be used to describe the location of the MP.11, for example "Main Lobby."

Contact Name, Contact Email, and Contact Phone

In these fields, you can enter the details of the person to contact.

Mode of Operation

Lets you choose one of two operating modes for your device: **Bridge** mode or **Routing** mode.

The following fields are described as follows:

ObjectID

This field shows the OID of the product name in the MIB.

Ethernet MAC Address

The MAC address of the Ethernet interface of the device.

Descriptor

Shows the product name and firmware build version.

Up Time

How long the device has been up and running.

Related CLI commands:

<code>show system</code>	<code>set sysname <name></code>
<code>set sysloc <location></code>	<code>set sysctname <contact name></code>
<code>set systemail <contact e-mail></code>	<code>set systcphone <contact phone></code>

IP CONFIGURATION

The IP Configuration window lets you change the MP.11 IP parameters. These settings differ when the MP.11 is in router mode.

To go to this page, click the **Configure** button, the **Network** tab, then the **IP Configuration** sub-tab.

The screenshot shows the web interface for configuring the IP settings of a Tsunami MP.11 device. On the left is a sidebar with buttons for 'Status', 'Configure' (highlighted in orange), 'Monitor', and 'Commands'. The main area has a top navigation bar with tabs for 'Telnet', 'Serial', 'HTTP', 'Security', and 'Filtering'. Below this is a sub-navigation bar with 'System', 'Network' (highlighted in orange), 'Interfaces', and 'SNMP'. The 'Network' tab is active, showing the 'IP Configuration' sub-tab (highlighted in orange) and the 'DHCP P.A.' sub-tab. The 'IP Configuration' sub-tab contains the following fields: 'IP Address Assignment Type' (a dropdown menu set to 'Static'), 'IP Address' (text box with '10.0.0.1'), 'Subnet Mask' (text box with '255.255.255.0'), 'Default Router IP Address' (text box with '10.0.0.1'), and 'Default TTL' (text box with '64'). At the bottom of the form are 'OK' and 'Cancel' buttons.

If the device is configured in **Bridge** mode, you can set the following parameters:

IP Address Assignment Type

Select **Static** if you want to assign a static IP address to the MP.11; select **Dynamic** to have the device run in DHCP client mode, which gets an IP address automatically from a DHCP server over the network. If you do not have a DHCP server or if you want to manually configure the IP settings, set this parameter to **Static**.

You can set the remaining parameters only when the IP Address Assignment Type is set to **Static**.

IP Address

The static IP address of the MP.11 (default IP address is 10.0.0.1).

Subnet Mask

The mask of the subnet to which the MP.11 is connected (default subnet mask is 255.0.0.0).

Default Router IP Address

The IP address of the default gateway.

Default TTL

The default time-to-live value.

Related CLI commands:

```
set ipaddrtype <static/dynamic>
set ipaddr 1 ipaddress <IP address>
set ipaddr 1 ipsubmask <subnet mask>
set ipaddr 1 ipgw <gateway IP address>
```

or, for example:

```
set ipaddr 1 ipaddress <IP address> ipsubmask <subnet mask>
```

Interfaces

The **Interfaces** configuration pages let you change the MP.11 Ethernet and wireless parameters. The **Wireless – Slot A** tab is displayed by default when you click the **Interfaces** tab.

Wireless Slot

To configure the wireless interface, click the **Configure** button followed by the **Interfaces** tab; then click the **Wireless Slot** sub-tab.

The wireless interface can be placed in either WORP Base or WORP Satellite mode (selected from the **Interface Type** drop-down box). (See “Wireless Outdoor Router Protocol” on page 34 for more information.)

The wireless interface settings differ per mode.

The screenshot shows the configuration interface for the Tsunami MP.11 device. The 'Interfaces' tab is selected, and the 'Wireless - Slot A' sub-tab is active. The configuration fields are as follows:

- Interface Type: Worp Satellite
- MAC Address: 00:02:2D:70:FE:69
- Base Station System Name: eagles
- Note: Base Station System Name is the System Name found on the system page of the Base Station this satellite is connecting to, if blank satellite can connect to any Base Station
- Network Name: sixers
- Frequency Channel: 5 - 2.432 GHz
- Data Rate: 11 Mbits/s
- Satellite Density: Large
- RegistrationTimeout: Large
- Network Secret: Medium
- Input bandwidth limit (in kbits/s): Mini
- Output bandwidth limit (in kbits/s): 11008

Buttons for 'OK' and 'Cancel' are located at the bottom of the configuration window.

You can change the following parameters:

Interface Type

The interface type can be **Worp Satellite** or **Worp Base**. *See "Wireless Outdoor Router Protocol" on page 34.)

Base Station System Name

The name found on the system page of the Base Station to which this satellite is connecting. If blank, this satellite can connect to any Base Station.

Network Name

A network name is name given to a network so that multiple networks can reuse the same frequency without problems. A satellite can only register to a base if it has the same Network Name. The Network Name is one of the parameters that allow a Subscriber Unit to register on a Base Station. The Base Station System Name and Frequency Channel also are parameters to guide the SU to the proper Base Station on the network, but they provide no security. Basic security is provided through encryption, as it causes none of the messages to be sent in the clear. Further security is provided by mutual authentication of the Base Station and Subscriber Unit using the Network Secret. The list of parameters to configure for registration of the SU on a Base Station are:

- Network Name
- Base Station System Name (if used)
- Channel Frequency
- Encryption (when used)
- Network Secret

Frequency Channel

The frequency channel the MP.11 uses for communicating with remotes. The frequency channel can be set in the range 1 to 11 for the USA and Canada, or 1 to 13 for Europe, or 1 to 14 for Japan (see “Radio Specifications” [on page 79](#)).

Data Rate

The rate at which data is to be transferred. The default data rate is 11 Mbps. The SU must never be set to a lower data rate than the Base Station because timeouts will occur at the Base Station and communication will fail.

Satellite Density

The Satellite Density setting is a valuable feature for achieving maximum bandwidth in a wireless network. It influences the receive sensitivity of the radio interface.

Registration Timeout

This is the registration process time-out of a satellite on a base. Default is 3 seconds.

Network Secret

A network secret is a secret password given to all nodes of a network. A satellite can only register to a base if it has the same Network Secret. The Network Secret is sent encrypted and can be used as a security option. Also see “Network Name.”

Input Bandwidth Limit

This parameter limits the data traffic received from the wireless interface.

Output Bandwidth Limit


This parameter limits the data traffic from the MP.11 to wireless stations.

Related CLI commands:

```
set wif 3 channel 10
set wif 3 netname <network name>
```

Ethernet Port

To configure the Ethernet interface, click the **Configure** button, the **Interfaces** tab, and the **Ethernet** sub-tab.



You can set the desired speed and transmission mode from this tab.

- **Half-duplex** means that only one side can transmit at a time.
- **Full-duplex** allows both sides to transmit.
- **Auto-duplex** selects the best transmission mode for the given configuration.

The recommended setting is **auto-speed-auto-duplex**.

Related CLI Commands:

```
show ethernet
show ethermacaddr
set ethernet 1 etherspeed <autospeedauto/autospeedhalf/
100auto/100full/100half/10full/10half>
```

Wireless Outdoor Router Protocol

The Wireless Outdoor Router Protocol (WORP) is a polling algorithm designed for wireless outdoor networks. WORP takes care of the performance degradation incurred by the so-called “hidden-node” problem, which can occur when standards-based 802.11b wireless LAN technology is used for outdoor building-to-building connectivity. In this situation, when multiple radios send an RTS, if another radio is transmitting, it corrupts all data being sent, degrading overall performance. The WORP polling algorithm ensures that these collisions cannot occur, which increases the performance of the overall network significantly.

WORP dynamically adapts to the number of satellites that are active on the network and the amount of data they have queued to send.

Satellite Density

The Satellite Density setting is a valuable feature for achieving maximum bandwidth in a wireless network. It influences the receive sensitivity of the radio interface. This feature improves operation in environments with a high noise level. Reducing the sensitivity of the radio enables unwanted “noise” to be filtered out. (It disappears under the threshold.)

You can configure the Satellite Density to be **Large**, **Medium**, **Small**, **Mini**, or **Micro**. The default value for this setting is **Large**. The smaller settings are appropriate for high noise environments; a setting of **Large** would be for a low noise environment.

A long distance link may have difficulty maintaining a connection with a small density setting because the wanted signal can disappear under the threshold. Both noise level and distance between the peers in a link should be considered when configuring this setting. The threshold should be chosen higher than the noise level, but sufficiently below the signal level. A safe value is 10 dB below the present signal strength.

If the Signal-to-Noise Ratio (SNR) is not sufficient, a lower data rate selection may be necessary, or use of antennas with higher gain to increase the margin between wanted and unwanted signals. In a point-to-multipoint configuration, the Base should have a density setting suitable for all of its registered Satellites, especially the ones with the lowest signal levels (longest links).

Take care when configuring a remote interface; check the available signal level first, using Remote Link Test.

Warning!

When the remote interface accidentally is set at too small a value and communication is lost, it cannot be reconfigured remotely and a local action is required to bring the communication back. Therefore, the best place to experiment with the level is at the unit that can be managed without going through the link; if the link is lost, the setting can be adjusted to the correct level to bring the link back.

To set the Satellite Density, click the **Configure** button, then the **Interfaces** tab and the **Wireless – Slot A** sub-tab. Make your density selection from the drop-down menu. This setting requires a reboot of the unit.

Sensitivity threshold settings related to the density settings are:


Satellite Density	Large	Medium	Small	Mini	Micro
Receive Sensitivity Threshold	-99 dBm	-90 dBm	-85 dBm	-72 dBm	-66 dBm
Defer Threshold	-95 dBm	-85 dBm	-75 dBm	-62 dBm	-56 dBm

MONITORING SETTINGS

The MP.11 offers various facilities to monitor its operation and interfaces. Only the most significant monitoring categories are mentioned here.

Wireless

To monitor the wireless interfaces, click the **Monitor** button and the **Wireless** tab.. This tab lets you monitor the general performance of the radio and the performance of the WOPR Base or WOPR Satellite interfaces.



The screenshot shows a web-based monitoring interface. On the left is a sidebar with buttons: Status, Configure, Monitor (highlighted in orange), and Commands. The main area has a top navigation bar with tabs: Link Test, Interfaces, IP ARP Table, IP Routes, Learn Table, and a sub-tab bar with Wireless (highlighted in orange), ICMP, Radius, Per Station, and Features. Under the Wireless tab, there are sub-tabs: General (highlighted in orange) and Worp. The General sub-tab displays a table of statistics for 'Wireless-slot A'.

Wireless-slot A	
Transmitted Fragment Count	0
Multicast Transmitted Frame Count	0
Failed Count	0
FCS Error	0
Multicast Received Frame Count	0
Received Fragment Count	1443
WEP Undecryptable Count	0

Interfaces

To monitor transmission details, click the **Monitor** button and the **Interfaces** tab.. The **Interfaces** tab provides detailed information about the MAC-layer performance of the MP.11 interface.

Type	ethernet-csmacd
Description	0.0
MIB Specific Definition	wlc0
Physical Address	00:02:2D:7F:18:56
Time Since Last Change(DD:HH:MM:SS)	00:00:47:57
Operational Status	Up
Admin Status	Up
Speed	2000000
Maximum Packet Size	1500
In Octets (bytes)	0
In Unicast Packets	0
In Non-unicast Packets	0
In Discards	0
In Errors	0
Unknown Protocols	0
Out Octets (bytes)	0
Out Unicast Packets	1
Out Non-unicast Packets	0
Out Discards	0
Out Errors	0
Output Queue Length	0

Related CLI commands:

```
show wif
show worp
show worpcfg
```


SECURITY SETTINGS

To prevent misuse, the MP.11 provides wireless data encryption and password-protected access. It is important to set the encryption parameters and change the default passwords.

Encryption

You can protect the wireless data link by using encryption. Both ends of the wireless data link must use the same parameter values.

To set the encryption parameters, click the **Configure** button, the **Security** tab, and the **Encryption** sub-tab.



You can set the following encryption parameters:

Encryption Status

This parameter enables or disables WEP encryption.

Encryption Key 1 – 4

These WEP encryption keys require an alphanumeric string. The length of the string determines the key length. Correct string lengths are 5 or 13 alphanumeric characters, or 10 or 26 hexadecimal digits.

Encrypt Data Transmissions Using

This parameter determines which encryption key is used.

Related CLI commands:

```
show wifsec                               set wifsec 3 encryptkeytx <1 - 4>
set wifsec 3 encryptkey1 <key 1>         set wifsec 3 encryptallowdeny <enable/disable>
```


Passwords

Access to the MP.11 is protected with passwords. The default password is **public**.

Changing the Telnet Password

To change the telnet password, click the **Configure** button and the **Telnet** tab.

Enter the new password in the **Password** field; repeat it in the **Confirm** field and click **OK**.

Related CLI commands:

```
show telnet
set tellogintout <login timeout>
set telport <port number>
set telsessions <maximum number of sessions>
set telsessiontout <inactivity timeout>
```

Changing the Web Interface Password

To change the password of the Web Interface, click the **Configure** button and the **HTTP** tab.

Enter the new password in the **Password** field; repeat it in the **Confirm** field and click **OK**.

Related CLI commands:

```
show http
set httppasswd <password>
set httpport <port number>
set httpstatus <0 - 15>
```

Changing the SNMP Password

You can set a read and a read-and-write password for SNMP. The password used during login determines the type of access.

You can change these passwords as follows:

Click the **Configure** button and the **SNMP** tab. Enter the new password in the **Password** field; repeat it in the **Confirm** field and click **OK** when you are done.

Related CLI commands:

```
show snmp
set snmprpasswd <read password>
set snmprwpasswd <read/write password>
set snmpstatus <0 - 15>
```

UPGRADING THE MP.11

The MP.11 is equipped with embedded software that can be updated. Updates can be found on our website:

<http://www.proxim.com>

Updating the embedded software is described in “Image File Download” on page 71. A TFTP server is required to transfer the file to the MP.11.

Chapter 5. Web Interface

This section covers the Web Interface of the MP.11. The interface is described hierarchically according to the buttons on the left side of the Web page:

- Status
- Configure
- Monitor
- Commands

For an introduction to the basics of MP.11 management, see “Chapter 4. Basic Management” on page 25.

STATUS

The **Status** tab is displayed automatically when the user logs into the Web Interface. It can also be accessed by clicking the **Status** button on the left side of the window.

The **Status** tab shows the **System Status** and the **System Traps**.

Status

System Status

IP Address	10.0.0.1	Contact	Contact Name
Name	Wireless Outdoor Router	Location	Contact Location
Object ID	1.3.6.1.4.1.11898.2.4.9	Up Time (DD:HH:MM:SS)	00:00:11:22

System Traps

Select All Deselect All

Description	Severity	Time Stamp
<input type="checkbox"/> OR Cold Started.	Informational	0 days 0 hrs 0 m 0 s

Delete

System Status

In this section, the basic system status is shown, including the version number of the embedded software.

Systems Traps

This section shows the status of system traps. System traps occur when the MP.11 encounters irregularities. Deleting system traps has no effect on the operation of the MP.11. System traps are also sent to an SNMP manager station (if so configured).

CONFIGURE

Use the **Configure** section to change the settings of the MP.11. There are nine tabs in this section.

1) System

Click the **Configure** button and the **System** tab.

The screenshot displays the 'Configure' section of the Tsunami MP.11 web interface. On the left, there are four buttons: 'Status', 'Configure' (highlighted in orange), 'Monitor', and 'Commands'. The main area shows the 'System' tab selected, with other tabs like 'Network', 'Interfaces', 'SNMP', 'Telnet', 'Serial', 'HTTP', 'Security', and 'Filtering' visible at the top. The 'Information' section contains the following fields and values:

Name	Wireless Outdoor Router
Location	Contact Location
Contact Name	Contact Name
Contact Email	name@Organization.com
Contact Phone	Contact Phone Number
Object ID	1.3.6.1.4.1.11898.2.4.9
Ethernet MAC Address	00:01:2D:01:24:03
Descriptor	Wireless Outdoor Router vBeta Bld#12 v0.98.98 SN- 01241 v0.0
Up Time (DD:HH:MM:SS)	00:00:13:02
Mode of Operation	Bridge

At the bottom of the form are 'OK' and 'Cancel' buttons.

In this section, you can enter or view the basic system information. These settings do not influence the operation of the MP.11, with the exception of **Mode of Operation**. **Mode of Operation** sets the MP.11 as **bridge** (layer 2) or as **router** (layer 3). “See System Configuration” on page 29 for more information.

2) Network

IP Configuration

The screenshot shows the 'IP Configuration' window. The 'Network' tab is selected, and the 'IP Configuration' sub-tab is active. The configuration fields are as follows:

Field	Value
IP Address Assignment Type	Static
IP Address	10.0.0.1
Subnet Mask	255.255.255.0
Default Router IP Address	10.0.0.1
Default TTL	64

Buttons: OK, Cancel

Click the **Configure** button, the **Network** tab, and the **IP Configuration** sub-tab to view and configure local IP address information. When the MP.11 is in **bridge** mode, only one IP address is needed. This IP address can also be changed with ScanTool. In **routing** mode, both Ethernet and wireless interfaces require an IP address.

DHCP Relay Agent

The screenshot shows the 'DHCP Relay Agent' window. The 'Network' tab is selected, and the 'DHCP Relay Agent' sub-tab is active. The configuration is as follows:

Field	Value
DHCP Relay	Disable


Buttons: OK, Cancel

Table:

Server IP address	Comment	Status
Add Table Entries		
Edit/Delete Table Entries		

Click the **Configure** button, the **Network** tab, and the **DHCP R A** sub-tab to enable the MP.11 DHCP relay agent. When enabled, the DHCP relay agent forwards DHCP requests to the set DHCP server.

To add entries to the table of DHCP Relay Agents, click “Add Table Entries”; the following window is displayed.



The screenshot shows a web interface for configuring a device. On the left is a sidebar with buttons: Status, Configure (highlighted in orange), Monitor, and Commands. The main area has tabs: Telnet, Serial, HTTP, Security, Filtering, System, Network (highlighted in orange), Interfaces, and SNMP. Under the Network tab, there are sub-tabs: IP Configuration and DHCP R A (highlighted in orange). The DHCP R A sub-tab contains a table with columns: Server IP Address, Comment, and Status. Below the table are input fields for 'Server IP Address' and 'Comment', followed by a note: 'NOTE: The value added will only take effect after the device is rebooted.' At the bottom are 'Add' and 'Cancel' buttons.

Server IP Address	Comment	Status
<input type="text"/>	<input type="text"/>	

NOTE: The value added will only take effect after the device is rebooted.

Enter the **Server IP Address** and any optional comments; click **Add**.

To edit or delete entries in the table, click “Click to Edit/Delete Table Entries”; make your changes and click **OK**.

IP Routing

Click the Configure button, the Network tab, and the IP Routing sub-tab to display the IP routing table. Users can add routes or delete existing routes. This page is available only in router mode.

3) Interfaces

Wireless Slot A

Click the **Configure** button, the **Interfaces** tab, and the **Wireless Slot A** sub-tab to change the wireless interface settings. See “Wireless Slot” on page 31 for an explanation this window’s fields.

The screenshot shows the 'Wireless Slot A' configuration window. The interface has a sidebar on the left with buttons for 'Status', 'Configure', 'Monitor', and 'Commands'. The main area has tabs for 'System', 'Network', 'Interfaces', and 'SNMP'. Under the 'Interfaces' tab, there are sub-tabs for 'Wireless - Slot A' and 'Ethernet'. The 'Wireless - Slot A' sub-tab is active, showing the following fields:


Interface Type	Worp Satellite
MAC Address	00:02:2D:7F:18:56
Base Station System Name (name found on system page of the Base Station this satellite is connecting to, if blank satellite can connect to any Base Station)	Wireless Outdoor Router
Network Name	OR_WORP
Frequency Channel	10 - 2.457 GHz
Data Rate	11Mbps
RegistrationTimeout	5
Retries	3
Network Secret	*****
Input bandwidth limit (in kbits/s)	11008
Output bandwidth limit (in kbits/s)	11008

At the bottom of the window are 'OK' and 'Cancel' buttons.

Ethernet

Click the **Configure** button, the **Interfaces** tab, and the **Ethernet** sub-tab to set the Ethernet speed and duplex mode.

Note: Current software always does auto-speed auto-duplex regardless of user selection.



The Base Station must not be configured at a higher data rate as any of the SUs, as the timeout of the Base Station is determined by its data rate. If one of the SUs has a lower data rate than the Base Station, it causes a timeout on all the longer data frames. It is okay if some (nearby) SUs are at a higher data rate than the Base Station.

4) SNMP

Click the **Configure** button and the **SNMP** tab to set passwords, set trap host IP addresses, and limit access to the MP.11 management interface. You can enable: All Interfaces, Only Ethernet, Only Slot A, or None.

Enable

Read Password Confirm

Read/Write Password Confirm

IP Access Table Trap Host Table

Trap Groups

Configuration Trap Status

Security Trap Status

Wireless Interface Trap Status

Operational Trap Status

Flash Memory Trap Status

TFTP Trap Status

Image Trap Status

OK Cancel

Trap Host Table

IP Address	Password	Comment	Status
Click to Add Table Entries		Click to Edit/Delete Table Entries	

Trap Groups

The user can enable or disable different types of traps in the system. By default, all traps are enabled.

Trap Host Table

This table shows the SNMP management stations to which the MP.11 sends system traps.

5) Telnet

Click the **Configure** button and the **Telnet** tab to manage telnet parameters, including **password** and **time out**.

The screenshot shows the 'Telnet' configuration window. On the left is a sidebar with buttons: 'Status', 'Configure' (highlighted in orange), 'Monitor', and 'Commands'. The main area has tabs: 'System', 'Network', 'Interfaces', 'SNMP', 'Telnet' (active), 'Serial', 'HTTP', 'Security', and 'Filtering'. The 'Telnet' tab contains the following settings: 'Enable' with a dropdown set to 'All Interfaces'; 'Port Number' with a text box containing '23'; 'Password' with a masked text box (dots) and a 'Confirm' label next to another masked text box; 'Login Timeout' with a text box containing '30'; and 'Session Idle Timeout' with a text box containing '900'. At the bottom are 'OK' and 'Cancel' buttons.

Note: To use HyperTerminal for CLI access, make sure to check “Send line ends with line feeds” in the ASCII Setup window (click **Properties** from the HyperTerminal window; select **Setup**, then **ASCII Setup**.)

6) Serial

Click the **Configure** button and the **Serial** tab to change the serial port settings.

The screenshot shows the 'Serial' configuration window. The sidebar is the same as in the Telnet window. The main area has the same tabs, but the 'Serial' tab is active. The 'Serial' tab contains the following settings: 'Baud Rate' with a dropdown set to '9600'; 'Data Bits' with a text box containing '8'; 'Parity' with a text box containing 'None'; 'Stop Bits' with a text box containing '1'; and 'Flow Control' with a dropdown set to 'None'. At the bottom are 'OK' and 'Cancel' buttons.

7) HTTP

Click the **Configure** button and the **HTTP** tab to view or change Web Interface parameters, including **password** and **time out**.

The screenshot shows the web interface with the 'Configure' button highlighted in orange on the left sidebar. The main content area has tabs for 'System', 'Network', 'Interfaces', and 'SNMP'. Under the 'Network' tab, there are sub-tabs for 'Telnet', 'Serial', 'HTTP' (which is selected and highlighted in orange), 'Security', and 'Filtering'. The 'HTTP' configuration form includes:

- 'Enable' checkbox: checked.
- 'All Interfaces' dropdown menu.
- 'Password' field: masked with dots.
- 'Confirm' field: masked with dots.
- 'Port' field: contains the value '80'.
- 'OK' and 'Cancel' buttons at the bottom right.

8) Security

MAC Authentication

Click the **Configure** button, the **Security** tab, and the **MAC Auth** sub-tab to build a list of authorized wireless stations that can register at the MP.11 and access the network.

The screenshot shows the web interface with the 'Configure' button highlighted in orange on the left sidebar. The main content area has tabs for 'System', 'Network', 'Interfaces', and 'SNMP'. Under the 'Network' tab, there are sub-tabs for 'Telnet', 'Serial', 'HTTP', 'Security' (which is selected and highlighted in orange), and 'Filtering'. Under the 'Security' tab, there are sub-sub-tabs for 'MAC Auth' (selected and highlighted in orange), 'Radius Auth', and 'Encryption'. The 'MAC Auth' configuration form includes:

- 'MAC Access Control Table' section.
- Table headers: 'MAC Address', 'Comment', and 'Status'.
- A note: 'NOTE: Changes made will only take effect after the device is rebooted.'
- 'OK', 'Cancel', and 'Back' buttons at the bottom.

RADIUS Authentication


Click the **Configure** button, the **Security** tab, and the **RADIUS Auth** sub-tab to set the IP address of the RADIUS server containing the central list of MAC addresses allowed to access the network.

RADIUS Server	
Primary	Backup
Server Status	Disable
IP Address	0.0.0.0
Destination Port	1812
Response Time (sec)	3
Maximum Retransmissions	3

In large networks with multiple MP.11 devices, you can maintain a list of MAC addresses on a centralized location using a RADIUS authentication server that grants or denies access. If you use this kind of authentication, you must specify at least the primary RADIUS server. The backup RADIUS server is optional.


Encryption

Click the **Configure** button, the **Security** tab, and the **Encryption** sub-tab to set encryption keys for the data transmitted and received by the MP.11. Note that all devices in one network must use the same encryption parameters to communicate to each other.



9) Filtering

Click the **Configure** button and the **Filtering** tab to configure packet filtering. Packet filtering can be used to control and optimize network performance.



Ethernet Protocol Filter

The Ethernet Protocol Filter blocks or forwards packets based upon the Ethernet protocols they support. Click the **Configure** button, the **Filtering** tab, and the **Ethernet Protocol Filter** sub-tab to enable or disable certain protocols in the table. Entries can be selected from a drop-down box.

- To add an entry to the table, click **Add Table Entries**, select the protocol name from the drop-down box and click the **Add** button.
- To edit or delete table entries, click **Edit/Delete Table Entries**, make your changes or deletions, and click **OK**.

Protocol Number	Protocol Name	Status
80:19	Apollo Domain	Disable
80:9B	Apple Talk 1 and 2	Disable
80:F3	Apple Talk ARP 1 and 2	Disable
08:AD	Banyan VINES	Disable
08:AF	Banyan VINES Echo	Disable
60:03	Decnet Phase IV	Disable
60:05	DEC Diagnostic	Disable
60:04	DEC LAT	Disable
60:07	DEC LAVC	Disable
60:01	DEC MOP Dump/Load	Disable
60:02	DEC MOP Rem Cons	Disable
80:40	DEC NetBIOS	Disable
80:05	HP Probe Control	Disable
80:D5	IBM SNA Services	Disable
08:00	IP	Disable
08:06	IP-ARP	Disable
81:37	Novell(ECONFIG E)	Disable
80:35	RARP Reverse ARP	Disable
81:4C	SNMP Over Ethernet	Disable
08:88	Xyplex	Disable

Ethernet Protocol Filtering

Blocks or forwards packets based upon the Ethernet protocols they support:

Ethernet: Packets are examined at the Ethernet interface.

Wireless: Packets are examined at the Wireless interface.

All Interfaces: Packets are examined at both interfaces.

Disabled: The filter is not used.

Filter Operation Type

Passthru: Only the enabled Ethernet Protocols listed in the Filter Table pass through the bridge.

Block: the Bridge blocks enabled Ethernet Protocols listed in the Filter Table.

IP Access Table

Entries in this table show which wireless stations are allowed to use SNMP, HTTP, and telnet management interfaces.


To add an entry, click **Add**; then specify the IP address and mask of the wireless stations to which you want to grant access. For example, **172.17.23.0/255.255.255.0** allows access from all wireless stations with an IP address in the 172.17.23.xxx range. Ensure that the wireless station you use is the first entry in the table.

Static MAC Pair Filtering

The Static MAC Address Filter optimizes the performance of a wireless (and wired) network. The filter is an advanced feature that lets you limit the data traffic between two specific devices (or between groups of devices based upon MAC addresses) through the wireless interface of the MP.11.

For example, if you have a server on your network with which you do not want wireless clients to communicate, you can set up a Static MAC Filter to block traffic between these devices. However, note that this is an advanced filter and it may be easier to control wireless traffic through other filter options, such as Protocol Filtering.

Click the **Configure** button, the **Filtering** tab, and the **Static MAC Pair Filtering** sub-tab to optimize the performance of wireless and wired networks by denying unwanted data traffic from specific devices.



Wired MAC Address

Enter the MAC address of the device on the Ethernet network that you want to prevent from communicating with a device on the wireless network.

Wired Mask

Enter the appropriate bit mask to specify the range of MAC addresses to which this filter is to apply. To specify on the single MAC address you entered in the Wired MAC Address filter, enter FF:FF:FF:FF:FF:FF (all zeroes).

Wireless MAC Address

Enter the MAC address of the wireless device that you want to prevent from communicating with a device on the wired network.

Wireless Mask

Enter the appropriate bit mask to specify the range of MAC addresses to which this filter is to apply. To specify only the single MAC address you entered in the Wireless MAC Address file, enter FF:FF:FF:FF:FF:FF (all zeroes).

Comment

Enter related information.

The entry is enabled automatically when saved. To edit an entry, click **Edit**. To disable or remove an entry, click **Edit** and change the **Status** field from **Enable** to **Disable** or **Delete**.

Spanning Tree Protocol

The Spanning Tree Protocol (STP) can be used to create redundant networks ("hot standby") and to prevent loops. If enabled, spanning tree prevents loops by disabling redundant links; if a link fails, it can automatically enable a backup link.

Storm Threshold

Storm Threshold is an advanced Bridge setup option that you can use to protect the network against data overload by:

- Specifying a maximum number of frames per second as received from a single network device (identified by its MAC address)
- Specifying an absolute maximum number of messages per port

The Storm Threshold parameters let you specify a set of thresholds for each port of the MP.11, identifying separate values for the number of broadcast messages per second and Multicast messages per second.

When the number of frames for a port or identified station exceeds the maximum value per second, the MP.11 ignores all subsequent messages issued by the particular network device, or ignores all messages of that type.

Click the **Configure** button, the **Filtering** tab, and the **Storm Threshold** sub-tab to prevent broadcast/multicast overload.

The screenshot shows the 'Storm Threshold' configuration window. The left sidebar contains buttons for 'Status', 'Configure', 'Monitor', and 'Commands'. The main area has tabs for 'System', 'Network', 'Interfaces', and 'SNMP'. Under 'Network', there are sub-tabs for 'Telnet', 'Serial', 'HTTP', 'Security', and 'Filtering'. The 'Filtering' sub-tab is active, showing the 'Storm Threshold' section. It contains three rows of input fields: 'Per Address Threshold', 'Ethernet interface Threshold', and 'Wireless - Slot A Threshold'. Each row has two columns: 'Broadcast' and 'Multicast'. All input fields are currently set to '0'. Below the input fields is a note: 'Note: Threshold values are in packets per second. 0=Protection disabled.' At the bottom are 'OK' and 'Cancel' buttons.

Per Address Threshold

Enter the maximum allowed number of packets per second.

Ethernet Threshold

Enter the maximum allowed number of packets per second.

Wireless Threshold

Enter the maximum allowed number of packets per second.

Broadcast Protocol Filtering

Click the Configure button, the Filtering tab, and the Broadcast Protocol Filtering sub-tab to deny specific IP broadcast, IPX broadcast, and multicast traffic.

The screenshot shows the 'Broadcast Protocol Filtering' configuration window. The left sidebar contains buttons for 'Status', 'Configure', 'Monitor', and 'Commands'. The main area has tabs for 'System', 'Network', 'Interfaces', and 'SNMP'. Under 'Network', there are sub-tabs for 'Telnet', 'Serial', 'HTTP', 'Security', and 'Filtering'. The 'Filtering' sub-tab is active, showing the 'Protocol Filtering' section. It contains a table with three columns: 'Protocol Name', 'Direction', and 'Status'. The table lists five protocols: 'Deny IPX RIP', 'Deny IPX SAP', 'Deny IPX LSP', 'Deny IP Broadcasts', and 'Deny IP Multicasts'. All 'Status' values are 'Disable'. Below the table is a link: 'Click to Edit Table Entries'.

Protocol Name	Direction	Status
Deny IPX RIP	Both	Disable
Deny IPX SAP	Both	Disable
Deny IPX LSP	Both	Disable
Deny IP Broadcasts	Both	Disable
Deny IP Multicasts	Both	Disable

You can configure whether this traffic must be blocked for Ethernet to wireless, wireless to Ethernet, or both.

MONITOR

Use this section of the interface to obtain detailed information about the settings and performance of the MP.11. There are 10 tabs in the **Monitor** section.

1) Wireless

General

Click the **Monitor** button and the **General** tab to monitor the general performance of the wireless interface.

Link Test

Interfaces

IP ARP Table

IP Routes

Learn Table

Wireless

ICMP

Radius

Per Station

Features

Status

Configure

Monitor

Commands

General

Worp

Wireless-slot A

Transmitted Fragment Count	0
Multicast Transmitted Frame Count	0
Failed Count	0
FCS Error	0
Multicast Received Frame Count	0
Received Fragment Count	1443
WEP Undecryptable Count	0

WORP


Click the **Monitor** button and the **WORP** tab to monitor the performance of the WORP Base or WORP Satellite interfaces.

The screenshot displays the WORP monitoring interface. On the left is a sidebar with buttons: Status, Configure, Monitor (highlighted in orange), and Commands. The main area has a top navigation bar with tabs: Link Test, Interfaces, IP ARP Table, IP Routes, Learn Table, Wireless (highlighted in orange), ICMP, Radius, Per Station, and Features. Below this is a sub-tab bar with General and Worp (highlighted in orange). The content area shows performance data for 'Wireless-slot A'.

Wireless-slot A	
Interface Type	Worp Satellite
Remotes	
Remote Partners	0
Registration Packet Counter Group	
Base Announces	0
Registration requests	0
Registration Reject	0
Authentication requests	0
Registration Process Counter Group	
Registration attempts	0
Registration Incompletes	0
Registration Time-outs	0
Registration Last Reason	1
Data Packet Counter Group	
Poll Data	0
Poll with No Data Sent	0
Poll replies with Data Sent	0
Poll replies with Data Sent (moreData flag set)	0
Poll replies with no data sent	0
Request for service	0
Data Process Counter Group	
Send Success	0
Send Retries	0
Send Failures	0
Receive Success	0
Receive Retries	0
Receive Failures	0
Poll no Replies	0

2) ICMP


Click the **Monitor** button and the **ICMP** tab to view the number of ICMP messages send and received by the MP.11. It includes **ping**, **route**, and **host unreachable** messages.



Messages Received		Messages Sent	
Total Messages	0	Total Messages	0
Errors	0	Errors	0
Destination Unreachable	0	Destination Unreachable	0
Time Exceeded	0	Time Exceeded	0
Parameter Problems	0	Parameter Problems	0
Source Quench	0	Source Quench	0
Redirects	0	Redirects	0
Echos	0	Echos	0
Echo Reply	0	Echo Reply	0
Time Stamps	0	Time Stamps	0
Time Stamp Reply	0	Time Stamp Reply	0
Address Mask	0	Address Mask	0
Address Mask Reply	0	Address Mask Reply	0

3) Radius


Click the **Monitor** button and the **Radius** tab to view information about the traffic exchanged with a RADIUS server.



Primary		Backup	
Access Requests	0	Access Requests	0
Access Accepts	0	Access Accepts	0
Access Retransmissions	0	Access Retransmissions	0
Access Rejects	0	Access Rejects	0
Access Challenges	0	Access Challenges	0
Malformed Access Responses	0	Malformed Access Responses	0
Authentication Bad Authenticators	0	Authentication Bad Authenticators	0
Timeouts	0	Timeouts	0

4) Per Station

Click the **Monitor** button and the **Per Station** tab to view the following information:



5) Features


Click the **Monitor** button and the **Features** tab to view the following information:

Feature	Supported	Licensed
Upstream Bandwidth WORP (in kbits/s)	11008	11008
Downstream Bandwidth WORP (in kbits/s)	11008	11008
Max. WORP Satellites	100	100
Max. Users On Satellite	65535	65535

Note: A Base Station shows how many WORP satellites it can support; the Subscriber Unit and Residential Subscriber Unit will show how many Ethernet hosts they support on their Ethernet port as the “Max Users on Satellite” parameter.

6) Link Test

Click the **Monitor** button and the **Link Test** tab to find out which wireless stations are in range and to check their link quality.



7) Interfaces

Click the **Monitor** button and the **Interfaces** tab to view detailed information about the IP-layer performance of the MP.11 interfaces. There are two sub-tabs: **Wireless – Slot A** and **Ethernet**. The following figure shows the Wireless interface; the same information is provided for the Ethernet interface on the Ethernet tab.

Configure	Wireless - Slot A	Ethernet
Monitor		
Commands		
	Type	ethernet-csmacd
	Description	0.0
	MIB Specific Definition	wlc0
	Physical Address	00:02:2D:7F:18:56
	Time Since Last Change(DD:HH:MM:SS)	00:00:47:57
	Operational Status	Up
	Admin Status	Up
	Speed	2000000
	Maximum Packet Size	1500
	In Octets (bytes)	0
	In Unicast Packets	0
	In Non-unicast Packets	0
	In Discards	0
	In Errors	0
	Unknown Protocols	0
	Out Octets (bytes)	0
	Out Unicast Packets	1
	Out Non-unicast Packets	0
	Out Discards	0
	Out Errors	0
	Output Queue Length	0

8) IP ARP Table

Click the **Monitor** button and the **IP ARP Table** tab to view the mapping of the IP and MAC addresses of all radios registered at the MP.11. This information is based upon the Address Resolution Protocol (ARP).

Interface	Physical Address	IP Address	Media Type
1	00:E0:B8:53:26:6D	10.0.0.2	Dynamic

9) Learn Table

Click the **Monitor** button and the **Learn Table** tab to view all MAC addresses the MP.11 has detected on an interface. The Learn Table displays information relating to network bridging. It reports the MAC address for each node that the device has learned is on the network and the interface on which the node was detected. There can be up to 10,000 entries in the Learn Table. This tab is only available in **bridge** mode.

Physical Address	Port	Status
00:E0:B8:53:26:6D	1	Learned

10) IP Routes

Click the **Monitor** button and the **IP Routes** tab to view all active IP routes of the MP.11. These can be either static or dynamic (obtained through RIP). This tab is only available in **router** mode, and you can add routes only when in **router** mode.



Destination	Subnet Mask	Next Hop	Interface	Metric
0.0.0.0	0.0.0.0	10.0.0.1	0	0
10.0.0.0	255.255.255.0	10.0.0.1	0	0
127.0.0.1	255.255.255.255	127.0.0.1	0	0

COMMANDS

This section describes the commands that you can perform with the Web Interface. There are five tabs in the Commands section.

1) Download

Click the **Commands** button and the **Download** tab to download image, configuration, and license files to the MP.11.

The screenshot shows the 'Download' tab selected in the web interface. On the left sidebar, the 'Commands' button is highlighted. The main content area shows the 'Download' tab with a 'System Information' section displaying 'Software Version 98.98' and 'Boot Loader Version 0.0'. Below this is the 'TFTP Information' section with four fields: 'Server IP Address' (10.0.0.2), 'File Name' (FILENAME), 'File Type' (Image), and 'File Operation' (Download). A note at the bottom reads: 'Note: Download copies files from the tftp server to the OR-2X00.' There are 'OK' and 'Cancel' buttons at the bottom right of the form.

Server IP address

Enter the TFTP Server IP address. (Double-click the TFTP server icon on your desktop and locate the IP address assigned to the TFTP server.)

File Name

Enter the name of the file to be downloaded.

File Type

Config, image, bootloader, or license.

File Operation

Download or Download and Reboot.

2) Upload

Click the **Commands** button and the **Upload** tab to upload a configuration file from the MP.11.

The screenshot shows the 'Upload' tab selected in the web interface. The 'Commands' button in the sidebar is also highlighted. The 'TFTP Information' section contains the following details:

System Information	
Software Version	98.98
Boot Loader Version	0.0

TFTP Information	
Server IP Address	10.0.0.2
File Name	FILENAME
Filetype	Config

Note: Upload copies files from the OR-2X00 to the tftp server.

3) Reboot

Click the **Commands** button and the **Reboot** tab to restart the embedded software of the MP.11. Configuration changes are saved and the MP.11 is reset.

The screenshot shows the 'Reboot' tab selected. The main content area displays the following message and button:

This Command will reboot the device

Reboot


CAUTION: *Rebooting the unit causes all users currently connected to lose their connection to the network until the MP.11 has completed the restart process and resumed operation.*

4) Reset

Click the **Commands** button and the **Reset** tab to restore the configuration of the MP.11 to the factory default values.


You can also reset the MP.11 from the RESET button located on the side of the unit. Because this resets the MP.11's current IP address, a new IP address must be assigned.

CAUTION: *Resetting the MP.11 to its factory default configuration permanently overwrites all changes made to the unit. The MP.11 reboots automatically after this command has been issued.*



5) Help

Click the **Commands** button and the **Help** tab to set the location of the help files of the Web Interface. If the help files cannot be found, pressing the ? button results in an error message. Upon installation, the help files are installed in the **C:\Program Files\Proxim\Tsunami MP.11** folder.



If you want to place these files on a shared drive, copy the Help folder to the new location and specify the new path in the **Help Link** box.

Chapter 6. Command Line Interface

INTRODUCTION

The Command Line Interface (CLI) provides a text-based interface with which you can configure and manage the MP.11 using commands. You can enter these commands or submit them in the form of a script to allow batch processing. Accessing the CLI was previously discussed in “Command Line Interface Overview” on page 22.

This chapter provides details about:

- Using Command Help [below](#)
- Viewing and Changing Parameters [on page 67](#)

Boot Loader Command Line Interface

The Boot Loader is started when the MP.11 is switched on or reset, and is responsible for starting the embedded software. The Boot Loader CLI (which has only a limited set of commands) is available when the MP.11 embedded software is not running.

USING COMMAND HELP

You can show CLI help by entering **help** at the command prompt. The CLI also provides context-specific help. To provide help in a specific situation, enter **?**. You can get help as follows:

- | | |
|--------------|---|
| ? | Lists all available commands. |
| s? | Lists all commands beginning with an s. |
| set | Shows the definition and a syntax example of the set command. |
| set ? | Shows the parameter name of the set command that must be entered at the position of the question mark. In this case you must enter a space before the ?. For example: |

```
download ?
<TFTP IP Address>

download 10.0.0.2 ?
<File Name>

download 10.0.0.2 image.bin ?
<file_type (config/image/Boot Loader/license)>

download 10.0.0.2 image.bin image
```

- | | |
|----------------|--|
| set ip? | Lists all parameters of the set command beginning with ip. |
|----------------|--|

Note that the Boot Loader CLI does not have command help.

VIEWING AND CHANGING PARAMETERS

You can view and change MP.11 parameters with the **SHOW** and **SET** commands, respectively. These commands are described below.

Show Command

The **show** command lets you view parameter and statistical values. You can view a single parameter, a group of parameters, or a table with parameters. A table consists of rows with similar parameters.

Example: To view all system parameters:

```
show system
```

This shows the current values of the system parameters.

Set Command

The **set** command lets you change parameter values. You can change a single parameter value and you can also modify a group of parameters, or a table with parameters. If a parameter requires more than one value, the values must be separated by spaces.

Example: To set the MP.11 IP address parameter:

```
set ipaddrtype static
set ipaddr 1 ipaddress 10.0.0.12
```

Some parameter values change only when the MP.11 is rebooted. In these cases, the CLI warns you that a reboot is required for the change to take effect.

ENTERING STRINGS

If you need to enter a string with spaces, you must use single or double quotes. For example, there is no need for quotes in the following because the string does not contain spaces:

```
set sysname Lobby
```

The following string, however, requires quotes because of the space between the words `Front` and `Lobby`.

```
set sysname "Front Lobby"
```

WORKING WITH TABLES

In some cases, parameters are stored in tables whose rows contain similar parameters. Command arguments involving tables have the following syntax:

```
<table name> <row> <parameter 1 name> <value 1> ... <parameter n name> <value n>
```

Viewing Table Contents

You can view the contents of a table as follows:

```
show <table name>
```

Example:

```
show snmpipaccesstbl
```

This command displays all parameter values of the SNMP IP access table (**snmpipaccesstbl**).

Creating a Table Row

You can create a table row as follows:

```
set <table name> 0 <parameter 1 name> <value 1> ... <parameter n name> <value n>
```

When you create a table row, you must use 0 as row index. Only the mandatory parameters are required. Optional parameters automatically receive the default value unless a value is given.

Example:

```
set snmpipaccesstbl 0 ipaddr 10.0.0.10 submask 255.255.0.0
```

This command adds a row to the SNMP IP access table (**snmpipaccesstbl**) with the IP address (**ipaddr**) and subnet mask (**submask**) parameters, which are respectively assigned 10.0.0.10 and 255.255.0.0.

Modifying a Table Entry

If you want to change a table entry, you must indicate the index of the table row and the parameter that must be modified.

Example:

```
set snmpipaccesstbl 1 ipaddr 10.0.0.11
```

This command changes the IP address (**ipaddr**) at row index 1 of the SNMP IP access table (**snmpipaccesstbl**) into 10.0.0.11.

Modifying Several Table Entries

You can also modify several table entries at once by indicating the index of the table row and the parameters that must be modified. With the **search** command, you can see which parameters are in the table.

Example:

```
set snmpipaccesstbl 1 ipaddr 10.0.0.12 submask 255.255.255.248 cmt "First Row"
```

Enabling, Disabling, or Deleting a Table Row

You can also enable, disable, or delete a row in a table. The syntax of this command is:

```
<table name> <row> <enable/disable/delete>, or  
<table name> <row> status <1/2/3>
```

Example 1: The following command enables the row at index 2 of the SNMP IP access table (**snmpipaccesstbl**).

```
set snmpipaccesstbl 2 enable
```

Example 2: The following command disables the row at index 2 of the SNMP IP access table (**snmpipaccesstbl**). The status codes have the following meaning: 1 is enable, 2 is disable, 3 is delete.

```
set snmpipaccesstbl 2 status 2
```

Chapter 7. Procedures

This chapter contains a set of procedures, as described in the following table:

Procedure	Description
TFTP Server Setup	Prepares the TFTP server for transferring files to and from the MP.11. This procedure is used by the other procedures that transfer files.
Image File Download	Upgrades the embedded software.
Configuration Backup	Saves the configuration of the MP.11.
Configuration Restore	Restores a previous configuration through configuration file download.
Soft Reset to Factory Default	Resets the MP.11 to the factory default settings through the Web or Command Line Interface.
Hard Reset to Factory Default	In some cases, it may be necessary to revert to the factory default settings (for example, if you cannot access the MP.11 or you lost the password for the Web Interface.
Force Reload	Completely resets the MP.11 and erases the embedded software. Use this procedure only as a last resort if the MP.11 does not boot and the “Hard Reset to Factory Default” procedure did not help. If you perform a “Forced Reload,” you must download a new image file as described in “Image File Download with the Boot Loader.”
Image File Download with the Boot Loader	If the MP.11 does not contain embedded software, or the embedded software is corrupt, you can use this procedure to download a new image file.

TFTP SERVER SETUP

To download or upload a file, you must connect to the computer with the TFTP server through the MP.11's Ethernet port. This can be any computer in the network or a computer connected to the MP.11 with a cross-over Ethernet cable. For information about installing the TFTP server, see “Installing Documentation and Software” on page 15.

Ensure that the upload or download directory is correctly set, the required file is present in the directory, and the TFTP server is running. The TFTP server must be running only during file upload and download. You can check the connectivity between the MP.11 and the TFTP server by pinging the MP.11 from the computer that hosts the TFTP server. The ping program should show replies from the MP.11.

IMAGE FILE DOWNLOAD

In some cases, it may be necessary to upgrade the embedded software of the MP.11 by downloading an image file. To download an image file through the Web Interface:

1. Set up the TFTP server as described in “TFTP Server Setup” on page 70.
2. Access the MP.11 as described in “Web Interface Overview” on page 21.
3. Click: **Commands → Download**.
4. Fill in the following details:

Server IP Address <IP address TFTP server>

File Name <image file name>

File Type Image

File Operation Download

5. Click **OK** to start the file transfer.

The MP.11 downloads the image file. The TFTP server program should show download activity after a few seconds. When the download is complete, the MP.11 is ready to start the embedded software.

CLI Image File Download

To download an image file:

1. Set up the TFTP server as described in “TFTP Server Setup” on page 70.
2. Access the MP.11 as described in “Command Line Interface Overview” on page 22.
3. Enter the following command:

download <IP address TFTP server> <image file name> **image**

The MP.11 downloads the image file. The TFTP server program should show download activity after a few seconds. When the download is complete and the system rebooted, the MP.11 is ready to start the embedded software.

CONFIGURATION BACKUP

You can back up the MP.11 configuration by uploading the configuration file. You can use this file to restore the configuration or to configure another MP.11 (see “Configuration Restore” on page 73).

To upload a configuration file through the Web Interface:

1. Set up the TFTP server as described in “TFTP Server Setup” on page 70.
2. Access the MP.11 as described in “Web Interface Overview” on page 21.
3. Click **Commands** → **Upload**.
4. Fill in the following details:
Server IP Address <IP address TFTP server>
File Name <configuration file name>
File Type Config
File Operation Upload
5. Click **OK** to start the file transfer.

The MP.11 uploads the configuration file. The TFTP server program should show upload activity after a few seconds. When the upload is complete, the configuration is backed up.

CLI Configuration File Upload

To upload a configuration file:

1. Set up the TFTP server as described in “TFTP Server Setup” on page 70.
2. Access the MP.11 as described in “Command Line Interface Overview” on page 21.
3. Enter the following command:
upload <IP address TFTP server> <configuration file name> **config**

The MP.11 uploads the configuration file. The TFTP server program should show upload activity after a few seconds. When the upload is complete and the system rebooted, the configuration is backed up.

CONFIGURATION RESTORE

You can restore the configuration of the MP.11 by downloading a configuration file. The configuration file contains the configuration information of an MP.11.

To download a configuration file through the Web Interface:

1. Set up the TFTP server as described in “TFTP Server Setup” on page 70.
2. Access the MP.11 as described in “Web Interface Overview” on page 21.
3. Click: **Commands → Download**.
4. Fill in the following details:
Server IP Address <IP address TFTP server>
File Name <configuration file name>
File Type Config
File Operation Download
5. Click **OK** to start the file transfer.

The MP.11 downloads the configuration file. The TFTP server program should show download activity after a few seconds. When the download is complete and the system rebooted, the configuration is restored.

CLI Configuration File Download

To download a configuration file:

1. Set up the TFTP server as described in “TFTP Server Setup” on page 70.
2. Access the MP.11 as described in “Command Line Interface” on page 22.
3. Enter the following command:
download <IP address TFTP server> <configuration file name> **config**

The MP.11 downloads the configuration file. The TFTP server program should show download activity after a few seconds. When the download is complete and the system rebooted, the configuration is restored.

SOFT RESET TO FACTORY DEFAULT

If necessary, you can reset the MP.11 to the factory default settings. Resetting to default settings means that you must configure the MP.11 anew.

To reset to factory default settings using the Web Interface:

1. Click the **Commands** button and the **Reset** tab.
2. Click the **Reset to Factory Default** button.

The device configuration parameter values are reset to their factory default values.

If you do not have access to the MP.11, you can use the procedure described in “Hard Reset to Factory Default” below as an alternative.

CLI Soft Reset to Factory Defaults


To reset to factory default settings:

```
set sysresettodefaults 1
```

HARD RESET TO FACTORY DEFAULT

If you cannot access the unit or you have lost its password, you can reset the MP.11 to the factory default settings. Resetting to default settings means you must configure the MP.11 anew.

To reset to factory default settings, press and hold the **RELOAD** button on the MP.11 unit for about 10 seconds. The MP.11 reboots and restores the factory default settings.



To access the MP.11 see “Chapter 3. Management Overview” on page 18.

FORCED RELOAD

With Forced Reload, you reset the MP.11 to the factory default settings and erase the embedded software. Use this procedure only as last resort if the MP.11 does not boot and the “Reset to Factory Defaults” procedure did not help. If you perform a Forced Reload, you must download a new image file with the Boot Loader (see “Image File Download with the Boot Loader” below).

Caution! *The following procedure erases the embedded software of the MP.11. This software image must be reloaded via an Ethernet connection with a TFTP server. The image filename to be downloaded can be configured with either ScanTool via Ethernet or with the Boot Loader CLI through the serial port to make the MP.11 functional again.*

To do a forced reload:

1. Press the RESET button on the MP.11 unit; the MP.11 resets and the LEDs flash.
2. Immediately press and hold the RELOAD button on the MP.11 unit for about 20 seconds. Now image and configuration are deleted from the unit.
3. Follow the procedure “Image File Download with the Boot Loader” to download an image file.

IMAGE FILE DOWNLOAD WITH THE BOOTLOADER

The following procedures download an image file to the MP.11 after the embedded software has been erased with Forced Reload or when the embedded software cannot be started by the Boot Loader.

A new image file can be downloaded to the MP.11 with Scan Tool or the Command Line Interface through the MP.11 serial port. In both cases, the file is transferred through Ethernet with TFTP. Because the CLI serial port option requires a serial RS-232C cable, Proxim recommends the ScanTool option.

ScanTool

To download an image file with the ScanTool:

1. Set up the TFTP server as described in “TFTP Server Setup” on page 70.
2. Run ScanTool on a computer that is connected to the same LAN subnet as the MP.11. ScanTool scans the subnet for MP.11 units and displays the found units in the main window. If in Forced Reload state (Power and Ethernet LEDs are amber), ScanTool will not find the device until the MP.11 bootloader times out, and the Power LED turns RED and the Ethernet LED goes OFF. Click **Rescan** to re-scan the subnet and update the display.
3. Select the MP.11 to which you want to download an image file and click **Change**.

4. Ensure that **IP Address Type Static** is selected and fill in the following details:
 - **IP Address** and **Subnet Mask** of the MP.11.
 - **TFTP Server IP Address** and, if necessary, the **Gateway IP Address** of the TFTP server.
 - **Image File Name** of the file with the new image.

5. Click **OK** to start the file transfer.

The MP.11 downloads the image file. The TFTP server program should show download activity after a few seconds. When the download is complete, the LED pattern should return to Forced Reload state (Power and Ethernet LEDs are amber). the MP.11 is ready to start the embedded software.

6. Press and release the **Reset** button. It may take several seconds to cycle through the Forced Reload LED pattern and through the initialization LED sequence.

After a Forced Reload procedure, the MP.11 returns to factory default settings and must be reconfigured. ScanTool can be used to set the system name and IP address.

To access the MP.11 see "Chapter 3. Management Overview" [on page 18](#).

Command Line Interface

To use the CLI through the serial port of the MP.11 you need the following items:

- A serial RS-232C cable with a male and a female DB-9 connector.
- An ASCII terminal program such as HyperTerminal.

Proxim recommends you switch off the MP.11 and the computer before connecting or disconnecting the serial RS-232C cable.

To download an image file:

1. Set up the TFTP server as described in "TFTP Server Setup" [on page 70](#).
2. Start the terminal program (such as HyperTerminal), set the following connection properties, and then connect:

COM port	(for example COM1 or COM2, to which the MP.11 serial port is connected)
Bits per second	9600
Data bits	8
Stop bits	1
Flow control	None
Parity	None

3. Press the **RESET** button on the MP.11 unit; the terminal program displays Power On Self Test (POST) messages.
4. When the **Sending Traps to SNMP manager periodically** message is displayed after about 30 seconds, press the **ENTER** key.

5. The command prompt is displayed; enter the following commands:

```
set ipaddr <IP address MP.11>
set ipsubmask <subnet mask>
set ipaddrtype static
set tftpipaddr <IP address TFTP server>
set tftpfilename <image file name>
set ipgw <gateway IP address>
reboot
```

For example:

```
set ipaddr 10.0.0.12
set ipsubmask 255.255.255.0
set ipaddrtype static
set tftpipaddr 10.0.0.20
set tftpfilename image.bin
set ipgw 10.0.0.30
reboot
```

The MP.11 reboots and downloads the image file. The TFTP server program should show download activity after a few seconds. When the download is complete, the MP.11 is ready for configuration.

To access the MP.11 see “Chapter 3. Management Overview” [on page 18](#). Note that the IP configuration in normal operation differs from the IP configuration of the Boot Loader.

Chapter 8. Specifications

This chapter provides Hardware and Radio Specifications.

HARDWARE SPECIFICATIONS

Physical Specifications (without metal base)	
Dimensions (h x w x l)	3.5 x 17 x 21.5 cm (1.5 x 6.75 x 8.5 in.)
Weight	0.68 kg (1.5 lb.)
Electrical Specifications	
Using the Power Adapter	
Voltage (Input)	100 to 240 VAC (50-60 Hz) @ 0.4 A
Voltage (Output)	12 VDC
Power Consumption	10 Watts (maximum)
Using Active Ethernet	
Input Voltage	42 to 60 VDC
Output Current	200mA at 48V
Power Consumption	10 Watts
Environmental Specifications	
Operating Temperature	0° to 55° C ambient temperature (without plastic cabinet)
Operating Humidity	95% maximum (non-condensing)
Storage Temperature	-20° to +75° C ambient temperature
Storage Humidity	95% maximum (non-condensing)
Interfaces	
Ethernet	10/100 Base-TX, RJ-45 female socket
Serial port	Standard RS-232C interface with DB-9, female connector
Active Ethernet	Category 5, foiled, twisted pair cables must be used to ensure compliance with FCC Part 15, subpart B, Class B requirements. Standard 802.3af pin assignments.
Wireless	Mini PC Card

RADIO SPECIFICATIONS

Channel Frequencies

The following table shows the channel allocations that vary from country to country. Values listed in bold indicate default channels and frequencies.

Channel ID	FCC/World (GHz)	ETSI (GHz)	France (GHz)	Japan (GHz)
1	2.412	2.412	--	2.412
2	2.417	2.417	--	2.417
3 (default in most countries)	2.422	2.422	--	2.422
4	2.427	2.427	--	2.427
5	2.432	2.432	--	2.432
6	2.437	2.437	--	2.437
7	2.442	2.442	--	2.442
8	2.447	2.447	--	2.447
9	2.452	2.452	--	2.452
10	2.457	2.457	2.457	2.457
11 (default in France)	2.462	2.462	2.462	2.462
12	--	2.467	2.467	2.467
13	--	2.472	2.472	2.472
14				2.484

For regulatory information, check the Regulatory Flyer included with the product.

Chapter 9. Troubleshooting

This chapter helps you to isolate and solve problems with your MP.11. In the event this chapter does not provide a solution or the solution does not solve your problem, please check our website:

<http://www.proxim.com>

Before you start troubleshooting, it is important that you have checked the details in the user's guides and manuals. For details about RADIUS, TFTP, terminal and telnet programs, and Web browsers, please refer to their appropriate documentation.

The following sections can help to solve your problem:

- LED Indicators below
- MP.11 Connectivity Issues [on page 81](#)
- Setup and Configuration [on page 84](#)

In some cases, rebooting the MP.11 clears the problem. If nothing else helps, consider a "Soft Reset to Factory Defaults" ([on page 27](#)) or a "Forced Reload" ([on page 75](#)). The Forced Reload option requires you to download a new image file to the MP.11.

LED INDICATORS

The MP.11 has three active LED indicators; the fourth LED is not used at this time. The LEDs are described in the following table.

Power	Ethernet Link	Wireless Link
OFF when no power is present or malfunctioning Green when power is present and the unit is operational. Amber when the unit cannot get a dynamic IP address, or in Forced Reload state when Ethernet LED also is amber.* Red when there is a fatal error in the unit.	OFF when not connected. Green when connected at 10 Mbps. Blinking Green when data sent. Amber when connected at 100 Mbps, or in Forced Reload state when Power LED also is amber.* Blinking Amber when data sent. Red when there is an error in data transfer.	OFF wireless interface is up properly, but no wireless link established. Green immediately after connecting a link. Blinking Green when data sent. Red when the wireless interface is down.
*See "Forced Reload" on page 75.		

MP.11 CONNECTIVITY ISSUES

The issues described in this section relate to the connections of the MP.11.

MP.11 Does Not Boot

The MP.11 shows no activity (the power LED is off).

1. Ensure that the power supply is properly working and correctly connected.
2. Ensure that all cables are correctly connected.
3. Check the power source.
4. If you are using an Active Ethernet splitter, ensure that the voltage is correct.

Serial Link Does Not Work

The MP.11 cannot be reached through the serial port.

1. Check the cable connection between the MP.11 and the computer.
2. Ensure that the correct COM port is used.
3. Start the terminal program; set the following connection properties (also see “HyperTerminal Connection Properties”), and then connect.


COM port	For example, COM1 or COM2, to which the MP.11 serial port is connected
Bits per second	9600
Data bits	0
Stop bits	1
Flow control	None
Parity	None
Line ends	Carriage return with line feed

4. Ensure that the MP.11 and the computer use the same serial port configuration parameters.
5. Press the RESET button on the MP.11 unit. The terminal program displays Power On Self Tests (POST) messages and displays the following after approximately 90 seconds:
Please enter password:


HyperTerminal Connection Properties

The serial connection properties can be found in HyperTerminal as follows:

1. Start HyperTerminal and select **Properties** from the **File** menu.
2. Select **Direct to Com 1** in the **Connect using:** drop-down list (depending upon the COM port you use); then click **Configure**. A window such as the following is displayed:



3. Make the necessary changes and click **OK**.
4. Click the **Settings** tab and then **ASCII Setup....** A window similar to the following is displayed:



5. Ensure that **Send line ends with line feeds** is selected and click **OK** twice. HyperTerminal is now correctly configured.

Setup and Configuration

Ethernet Link does not work

First check the Ethernet LED;

- Dim is “no media connected.”
- Green and steady is 10 Base-T
- Amber and steady is 100 Base-T
- Blinking Green or Amber is traffic

Verify pass-through versus errors over cable.

Cannot use the Web Interface:

1. Open a command prompt window and enter **ping** <ip address MP.11> (for example ping 10.0.0.1). If the MP.11 does not respond, make sure that you have the correct IP address. If the MP.11 responds, the Ethernet connection is working properly, continue with this procedure.
2. Ensure that you are using one of the following Web browsers:
 - Microsoft Internet Explorer version 5.0 or later.
 - Netscape version 6.0 or later.
3. Ensure that you are not using a proxy server for the connection with your Web browser.
4. Ensure that you have not exceeded the maximum number of Web Interface or CLI sessions (with the CLI command **show pelsessions**).
5. Double-check the physical network connections. Use a well known unit to ensure the network connection is properly functioning.
6. Perform network infrastructure troubleshooting (check switches, routers, and so on).

SETUP AND CONFIGURATION

The following issues relate to setup and configuration problems.

Lost the MP.11 Password

If you lost your password, you must reset the MP.11 to the default settings. See “Hard Reset to Factory Default” on page 74. The default password is **public**.

If you record your password, keep it in a safe place.

The MP.11 Responds Slowly

If the MP.11 takes a long time to become available, it could mean that:

- No DHCP server is available.
- The IP address of the MP.11 is already in use.

Verify that the IP address is assigned only to the MP.11. Do this by switching off the MP.11 and then pinging the IP address. If there is a response to the ping, another device in the network is using the same IP address. If the MP.11 uses a static IP address, switching to DHCP mode could remedy this problem. Also see “Dynamic IP Address with DHCP” on page 20.

- There is too much network traffic.

Web Interface Does Not Work

If you cannot connect to the MP.11 Web server through the network:

1. Connect a computer to the serial port of the MP.11 and check the HTTP status. The HTTP status can restrict HTTP access at different interfaces. For more information, see “Serial Port” on page 23.

Related CLI commands:

```
show httpstatus
set httpstatus 0      To disable the Web management at all interfaces.
set httpstatus 15     To enable at all interfaces.
```

2. Open a command prompt window and enter:

```
ping <ip address MP.11> (for example ping 10.0.0.1)
```

If the MP.11 does not respond, ensure that you have the correct IP address. If the MP.11 responds, the Ethernet connection is working properly, continue with this procedure.

3. Ensure that you are using one of the following Web browsers:
 - Microsoft Internet Explorer version 5.0 or later
 - Netscape version 6.0 or later
4. Ensure that you are not using a proxy server for the connection with your Web browser (with the CLI command **show pelsessions**).
5. Ensure that you have not exceeded the maximum number of Web Interface sessions.

Command Line Interface Does Not Work

If you cannot connect to the MP.11 through the network:

1. Connect a computer to the serial port of the MP.11 and check the SNMP table. The SNMP table can restrict telnet or HTTP access. For more information, see “Serial Port” [on page 23](#).
2. Open a command prompt window and enter: **ping** <ip address MP.11>
(for example **ping 10.0.0.1**).
 - If the MP.11 does not respond, ensure that you have the correct IP address.
 - If the MP.11 responds, the Ethernet connection is working properly, continue with this procedure.
3. Ensure that you have not exceeded the maximum number of CLI sessions.

TFTP Server Does Not Work

With TFTP, you can transfer files to and from the MP.11. Also see “TFTP Server Setup” [on page 70](#). If a TFTP server is not properly configured and running, you cannot upload and download files. The TFTP server:

- Can be situated either local or remote.
- Must have a valid IP address.
- Must be set for send and receive without time-out.
- Only must be running during file upload and download.

If TFTP server does not upload or download files, it could mean:

- The TFTP server is not running.
- The IP address of the TFTP server is invalid.
- The upload or download directory is not correctly set.
- The file name is not correct.

Online Help Is Not Available

Online help does not appear when the 'Question mark' button is clicked in the Web Interface:

1. Make sure that the Help files are installed on your computer or server. Also see "Installing Documentation and Software".
2. Verify if the path of the help files in the Web Interface refers to the correct directory. See "Help" on page 65.

Changes Do Not Take Effect

Changes made in the Web Interface do not take effect:

1. Restart your Web browser. Log into the MP.11 again and make changes. Reboot the MP.11 when prompted to do so.
2. Wait until the reboot is completed before accessing the MP.11 again.

Glossary

ARP

The Address Resolution Protocol (ARP) is intended to find the MAC address belonging to an IP address.

Authentication method

The process the MP.11 uses to decide whether a station that wants to register is allowed or not. IEEE 802.11 specifies two forms of authentication: open system and shared key; WOPR only supports shared key because of security constraints.

Authentication server “Shared Secret”

This is a kind of password shared between the MP.11 and the RADIUS authentication server. This password is used to encrypt important data exchanged between the MP.11 and the RADIUS server

Authentication server authentication port

This is a UDP port number (default is 1812), which is used to connect to the authentication server for obtaining authentication information.

Backbone

The central part of a network; the backbone network connects all remote and sub networks to each other and to the central infrastructure (such as the mail server, Internet gateway, and so on).

Base

If an interface is running in Outdoor mode (WOPR), it is either a base or a satellite interface. A base interface controls the communication on the channel and is located in the central part of the network cell. Multiple satellites can connect to one base; two bases cannot communicate with each other.

Broadcast Storm

A broadcast storm is a large series of broadcast packets (most often caused by wrong network configuration) that severely impact the network performance.

Client IP Address Pool

This is a pool of IP addresses from which the MP.11 can assign IP addresses to clients, which perform a DHCP Request.

Configuration Files

A configuration file contains the MP.11 configuration details. Configuration items include among others the IP address and other network-specific values. Configuration files may be uploaded to a TFTP server for backup and downloaded into the MP.11 for restoring the configuration.

DHCP Relay Agent

A feature of the MP.11 that intercepts DHCP requests from clients and forwards them to a DHCP server. For the client, the DHCP Relay Agent of the MP.11 functions like a DHCP server. This enables DHCP requests to pass router boundaries; for example, it is not required to have a DHCP server on every IP subnet.

Domain Name Server (DNS)

A domain name server is an Internet service that translates domain names into IP addresses. For example, www.ietf.org will be translated in 4.17.168.6.

Download

Downloading a file means copying a file from a remote server to a device or host. In case of the MP.11 downloading means transferring a file from a TFTP server to the MP.11.

Downstream

Downstream means a data stream from the central part of the network to the end user. See also **upstream**.

Dynamic Host Configuration Protocol

Dynamic Host Configuration Protocol (DHCP) is a method to dynamically assign IP addresses. If DHCP is enabled, the device or computer will broadcast a request that will be answered by a DHCP Server.

Encryption

Encryption is a means of coding data with a key before sending it across a network. The same key must be used to decode the information at the receiver. This way prevents unauthorized access to the data that is sent across the network.

Ethernet

Ethernet is the most widely installed Local Area Network (LAN) technology. The MP.11 supports both 10 and 100 Mbps and half and full duplex.

Gateway

A gateway is network device that connects multiple (IP) networks to each other. A gateway can perform protocol conversion.

Group

A group is logical collection of network parameters. For example, the System Group is composed of several parameters and tables giving system information of the MP.11. All items for a group are grouped under one tab of the Web Interface and start with the same prefix for the command line interface.

HTTP

Hypertext Transfer Protocol (HTTP) is the protocol to transport Web pages. When you access the Internet with your browser, the HTTP protocol is used for data transport (<http://www.Tsunamiwireless.com>). When you access the MP.11 using the Web Interface, HTTP is used to transport the information.

ICMP

Internet Control Message Protocol (ICMP) is used by computers and devices to report errors encountered during processing packets, and to perform other IP-layer functions, such as diagnostics ('ping').

Image

The image is the binary executable of the embedded MP.11 software. To update the MP.11 you must download a new image file.

IP Address

A unique numerical address of a computer attached to the Internet or Intranet. An IP (Internet Protocol) address consists of a network part and part for a host (computer) number. An IP address is represented by four numbers in the range 0 - 255 separated by dots: for example 10.0.10.1 and 172.21.43.214. See also **subnet mask**.

LAN

A Local Area Network (LAN) is a network of limited size to which computers and devices can connect so that they can communicate with each other.

License file

A license file is used to enable certain features of the MP.11. The MP.11 already has a license file when it is shipped. When more features become available, you can purchase a license file and download it to the MP.11 to enable these additional features.

MAC Address

A MAC (Media Access Control) address is a globally unique network device address, which is hardware bound. It used to identify a network device in a LAN. A MAC address is represented by six two-digit hexadecimal numbers (0 - 9 and A - F) separated by colons: for example 00:02:2D:47:1F:71 and 00:D0:AB:00:01:AC.

Management Information Block (MIB)

A Management Information Block (MIB) is a formal description of a set of network objects that can be managed with the Simple Network Management Protocol (SNMP). A MIB can be loaded by a management application so that it knows the MP.11 specific objects. .

Network Mask

See **subnet mask**.

Parameter

A parameter is fundamental value that can be displayed and changed. For example, the MP.11 must have a unique IP address and the PC Cards must know which channels to use. You can view and change parameters with the Web Interface, command line interface and SNMP.

Password

The MP.11 is password protected. To access the MP.11 you need to enter a password before you can view or change its settings. The default password is 'public'.

Ping

Ping is a basic Internet program that lets you verify if a particular computer or device with a certain IP address is reachable. If the computer or device receives the ping packet, it responds which gives the ping program the opportunity to display the round-trip time.

Remote

A remote is a base or a satellite interface. For a base interface, the number of remotes is the number of satellites registered; for a satellite interface, there will be only one remote, which is the base.

RIP

Routing Information Protocol (RIP) is used between routers to update routing information so that a router automatically 'knows' which port to use for a certain destination IP address.

Router

Routers forward packets from one network to another based on routing information. A router uses a dynamic routing protocol like RIP or static routes to base its forwarding decision on.

Satellite

If an interface is running in outdoor mode (WORP), it is either a base or a satellite interface. Satellite interface behavior is controlled by the base to which it is registered. Satellites are located in the remote locations of a network cell. Multiple satellites can connect to one base; two satellites cannot communicate with each other. See also WORP and base.

ScanTool

A computer program that can be used to retrieve or set the IP address of a locally connected MP.11.

Simple Network Management Protocol (SNMP)

A protocol used for the communication between a network management application and the devices it is managing. The network management application is called the SNMP manager; the devices it manages have implemented SNMP agents. Not only the MP.11 but also almost every network device contains a SNMP agent. The manageable objects of a device are arranged in a Management Information Base, also called MIB. The Simple Network Management Protocol (SNMP) allows managers and agents to communicate for accessing these objects.

Spanning Tree Protocol (STP)

The Spanning Tree Protocol (STP) can be used to create redundant networks ("hot standby") and to prevent loops. If enabled, spanning tree prevents loops by disabling redundant links; if a link fails, it can automatically enable a backup link.

Subnet Mask

A subnet mask is a bit mask that defines which part of an IP address is used for the network part and which part for a host (computer) number. A subnet mask is like an IP address represented by four numbers in the range 0 - 255 separated by dots. When the IP address 172.17.23.14 has a subnet mask of 255.255.255.0, the network part is 172.17.23 of the host number is 14. See also **IP address**.

Table

Tables hold parameters for several related items. For example, you can add several potential managers to the SNMP IP access table. Tables can be displayed using with the Web Interface, command line interface and SNMP.

Topology

Topology is the physical layout of network components (cable, stations, gateways, hubs, and so on).

Trap

A trap is used within SNMP to report an unexpected or unallowable condition.

Trivial File Transfer Protocol (TFTP)

Trivial File Transfer Protocol (TFTP) is a lightweight protocol for transferring files that is like a simple form of File Transfer Protocol (FTP). A TFTP client is implemented on the MP.11; using the upload and download commands, the MP.11 can respectively copy a file to or from a TFTP server. TFTP server software is provided on the MP.11 CD-ROM.

Upload

Uploading a file means copying a file from a network device to a remote server. In case of the MP.11 uploading means transferring a file from the MP.11 to a TFTP server. See also **download**.

Upstream

Upstream means a data stream from the end users to the central part of the network. See also **downstream**.

WEP

The Wired Equivalent Privacy (WEP) algorithm is the standard encryption method used to protect wireless communication from eavesdropping.

WORP

The Wireless Outdoor Router Protocol (WORP) was designed to optimize long distance links and multipoint networks with Hidden Node effect to eliminate collisions and loss of bandwidth.